





## USING SPECIAL NUMBERS

Special numbers are needed only if you would like to be able to place direct dial outbound calls during the rare occurrence that the phone has dialed 911. (When 911 is dialed, outbound dialing is temporarily restricted to Special Numbers only.) By entering Special Numbers (up to three) you will continue to be able to make outbound calls during these occurrences.

### TO ADD OR REPLACE A SPECIAL NUMBER:

1. Select  > **Parental Control**.
2. Enter your lock code to display the Parental Control menu.
3. Select **Special #s**.
4. Select a field for your entry and press .
5. Enter a special number and press .
6. Select **Done**  to return to the Parental Control menu.

#### Note:






The same number can be in both the Special Numbers and Phone Book Only directories.

©2006 Sprint Nextel. All rights reserved. SPRINT, the "Going Forward" logo, and other trademarks are trademarks of Sprint Nextel. All rights reserved.

## EDITING OR ADDING CONTACTS ENTRIES

You can easily add to or edit your Contacts list simply by selecting **Parental Control** from the main menu and then selecting **Edit Phone Book**.






### TO ADD A CONTACTS ENTRY:

1. Select  > **Parental Control**.
2. Enter your lock code to display the Parental Control menu.
3. Select **Edit Phone Book**.
4. Select **<Add Contact>** and press .
5. Enter a name for the entry and press .
6. Highlight the appropriate label for the phone number, enter the number, and press . (If necessary, select and enter other options items such as email or Web addresses.)
7. Select **Save** .

#### Tip:

You can also add or edit your Contacts list by selecting **Contacts** from the main menu and entering your lock code to begin adding and editing contacts even when your phone is in restricted mode.

### TO EDIT A CONTACTS ENTRY:

1. Select  > **Parental Control**.
2. Enter your lock code to display the Parental Control menu.
3. Select **Edit Phone Book**.
4. Highlight an entry and press .
5. Press **Options**  and select **Edit**.
6. Highlight the information you wish to change, make any desired changes, and press . Repeat this step to change other information.
7. Press **Save** .

#### Note:

Regardless of whether you set Lock Services, Change Lock, or Limit Use from the Security menu or from the Parental Control menu, the most recent setting takes precedence.



## PARENTAL CONTROL Quick Start Guide




## PARENTAL CONTROL

Your phone's Parental Control feature allows you to restrict incoming and outgoing direct dial calls as well as limit access to services such as Sprint PCS Vision® and Sprint PCS Ready Link®. You can also easily edit your Contacts/Phone Book entries while Limit Use features are enabled.

## ENTERING YOUR LOCK CODE

You must enter a lock code to access the Parental Control menu or to unlock a phone that has been locked.

### TO ACCESS THE PARENTAL CONTROL MENU:

1. Select  > **Parental Control**.
2. Enter your lock code to display the Parental Control menu.


### Tip:

The lock code for both the Security and Parental Control menus is the same. If you can't recall your lock code, try using the last four digits of either your Social Security number or wireless phone number; or try 0000 or NATL (6285). If none of these work, call Sprint Customer Service at 1-888-211-4PCS (4727).

## CHANGING YOUR LOCK CODE

You can easily change your lock code to any four-digit number sequence you choose.

### TO CHANGE YOUR LOCK CODE:

1. Select  > **Parental Control**.
2. Enter your lock code to display the Parental Control menu.
3. Select **Change Lock**.
4. Enter and re-enter a new lock code.


### Tip:

To ensure the security of settings, parents should change the lock code once they've set their initial settings

## RESTRICTING CALLS

You can restrict both incoming and direct outgoing voice calls to phone book only or to special numbers only. Regardless of the restrictions you set, you will always be able to call 911 or Sprint Customer Service.

### TO RESTRICT INCOMING OR OUTGOING CALLS:

1. Select  > **Parental Control**.
2. Enter your lock code to display the Parental Control menu.

3. Select **Limit Use**  > **Outgoing Calls** or **Incoming Calls**.

4. Select an option and press .

- **Phone Book Only** lets you make or receive direct dial calls from Contacts/Phone Book entries, voicemail, or special numbers only.
- **Special #s Only** lets you make direct calls to or receive calls from three special numbers only. (See "Using Special Numbers.")

5. To remove restrictions select **Allow All**.


### Note:

Whenever calls have been restricted on your phone, **RESTRICTED** will appear in red on the standby screen.

## LOCKING SERVICES

With this feature, you can choose to restrict access to Sprint PCS Vision services and Sprint PCS Ready Link calls.

### TO LOCK SERVICES:

1. Select  > **Parental Control**.
2. Enter your lock code to display the Parental Control menu.
3. Select **Lock Services** > **PCS Vision** or **Ready Link**.
4. Select **Locked**. (Select **Unlocked** to remove restrictions.)

Sprint®

