



Sprint PCS VisionSM Guide



Welcome to Sprint PCS VisionSM

Sprint and Nextel have come together to offer you more choice and flexibility to do whatever you want, whenever you want. This powerful combination brings you access to more products, more services, and more of what you need to do more of what you want. Welcome to a future full of possibility. Welcome to the new Sprint.

Sprint helps you get the most from your wireless service with the technology of Sprint PCS VisionSM while on the Nationwide Sprint PCS Network. You'll enjoy advanced wireless services that are easy to learn and use, plus the voice clarity you've come to expect from Sprint.



Sprint PCS Picture MailSM – Instantly shoot, share and print sharp high resolution, digital pictures and take and send short video clips with your phone.



Messaging – Send and receive emails and chat on your phone.



Sprint TVSM – See and hear the latest news, sports, weather, and more in full-color video and vivid sound while on the go.



Music – Stream music to your phone's built-in media player.



Games – Play exciting games with full-color graphics, sound, and vibration.



Ringers – Personalize your phone by downloading and assigning different ringers to numbers in your address book.



Screen Savers – Download unique images to use as screen savers – or make it easy to tell who's calling by assigning specific images to numbers in your address book.



Web – Stay informed on the go with your phone's access to full-color, graphic versions of popular Internet sites.



Sprint PCS Business ConnectionSM – Get secure, real-time access to your Microsoft[®] Outlook[®] or Lotus Notes[®] company email, calendar, business directory, and personal contacts.



Introduction to This User Guide

This guide introduces you to Sprint PCS Vision and all the advanced capabilities of this exciting, always-expanding service. You'll also find timely reminders and tips that will help you make the most of your Sprint PCS Vision experience.

Thank you for choosing Sprint.



Contents

Getting Started With Sprint PCS VisionSM	1
Your Sprint PCS Vision User Name	2
Finding Your User Name	2
Changing Your User Name and Password	3
Your Sprint PCS Vision Password	3
Creating Your Sprint PCS Vision Password	3
Retrieving/Resetting Your Sprint PCS Vision Password	4
Launching a Sprint PCS Vision Connection	5
Net Guard	6
Sprint PCS Vision Connection Status and Indicators	6
Navigating the Web With Your Phone	6
Your Phone’s Navigation Controls	7
Browsing the Web	7
Managing Sprint PCS Vision Online	9
Sprint PCS Picture MailSM	10
Taking Pictures	11
Creating Your Sprint PCS Picture Mail Password	11
Recording Videos	12
Sharing Sprint PCS Picture Mail	13
Sharing Sprint PCS Picture Mail From “In Phone”	13
Sharing Videos From “In Phone”	14
Sharing Sprint PCS Picture Mail From Messaging	15
Storing Pictures and Videos	15
Pictures: My Albums – In Phone	15
Videos: My Albums – In Phone	16
Managing Sprint PCS Picture Mail	18
Using the Sprint PCS Picture Mail Web Site	18
Managing Online Pictures and Videos From Your Phone	18
Sharing Online Sprint PCS Picture Mail	19
Accessing Online Picture and Video Options From Your Phone	19
Messaging	21
Accessing Messaging at www.sprint.com	22
SMS Text Messaging	22
Instant Messaging	25
Accessing Instant Messaging	25
Email – Sprint PCS Mail	26
Setting Up Your Sprint PCS Mail Account	26
Accessing Sprint PCS Mail Messages	27
End of Message Options	27

- Sending Sprint PCS Mail Messages28
- Managing Sprint PCS Mail Folders29
- Using Your Calendar29
- Managing Your Contacts30
- Using the Task List31
- Accessing External Email Accounts32
- Managing Your Sprint PCS Mail Settings34
- Notification Settings35
- Email – Additional Email Providers36
- Accessing Email36
- Wireless Chat37
- Experiencing a Chat Room37
- Accessing Wireless Chat Help38
- Sprint TVSM 39**
- Exploring Sprint TV Services40
- Accessing Your Channel Listings40
- Purchasing New Media Channels41
- Purchasing Media Channels on Your Phone41
- Purchasing Media Channels Online41
- Playing Media Clips42
- Music..... 43**
- Accessing Your Music Channel Listings44
- Purchasing New Music Channels44
- Purchasing Media Channels on Your Phone44
- Purchasing Media Channels Online45
- SIRIUS Music46
- Streaming Music46
- Sprint PCS Vision Premium Services Downloads 47**
- Accessing the Download Menus48
- Finding an Item to Download48
- Downloading an Item49
- Authorizing Premium Services Purchases50
- Managing Purchases at www.sprint.com51
- Using My Content Manager52
- Games..... 53**
- Purchasing and Downloading Games55
- Playing Games56
- Ringers 57**
- Purchasing and Downloading Ringers59
- Assigning Downloaded Ringers60

Screen Savers **61**
 Purchasing and Downloading Screen Savers63
 Assigning Downloaded Screen Savers64

Web..... **65**
 Web66
 Using the Browser Menu67
 Opening the Browser Menu67
 Bookmarks68
 Going to a Specific Web site68
 Restarting the Web Browser69
 Browser Menu Settings69
 Applications70
 Media Applications71
 Purchasing and Downloading Applications71
 Launching Downloaded Applications72

Sprint PCS Business ConnectionSM Personal Edition **73**
 Sprint PCS Business ConnectionSM Personal Edition74
 Accessing Sprint PCS Business Connection75

Sprint PCS Vision FAQs **76**
 What is Sprint PCS Vision?76
 What are the benefits of Sprint PCS Vision?76
 What services does Sprint PCS Vision provide?76
 How do I take advantage of Sprint PCS Vision?77
 How am I charged for Sprint PCS Vision Services?77
 What is the Content Catalog?77
 How much does it cost to purchase items from the Content Catalog?77
 Where is my content stored?78
 How can I access My Content Manager?78
 What messaging options are available with Sprint PCS Vision?78

Index..... **79**

Getting Started With Sprint PCS VisionSM

With your Sprint PCS Vision Service, you're ready to start enjoying the advantages of Sprint PCS Vision. If you haven't activated your phone, follow these simple steps to activate and set up your service:

- ▶ Press ***** **2** **TALK** on your phone.
– or –
- ▶ Dial **1-888-715-4588** from any phone.

You'll need the phone's Electronic Serial Number (ESN) for activation. To find your phone's ESN, turn the phone off and remove the battery. The ESN is an 11-digit number that usually begins with "ESN DEC:".

Note:

This guide is designed to introduce you to the features of Sprint PCS Vision. Some information may not apply to your phone. Please see your phone User Guide for your phone's specific information.

It's easy to get started.

Once you've signed up for service, this section will help you learn the basics of your Sprint PCS Vision services.

- **Using Your Sprint PCS Vision User Name and Password**
- **Connecting With Sprint PCS Vision**
- **Navigating the Web With Sprint PCS Vision**



Your Sprint PCS Vision User Name

When you buy a phone and sign up for service, you're automatically assigned a user name. Then, when you use Sprint PCS Vision Services, your user name is submitted to identify you to the Nationwide Sprint PCS Network. Your user name is also useful as an email address, as a way to personalize Internet services, and as an online virtual identity.

Your user name is typically based on your name and a number, followed by "@sprint.com." For example, the third John Smith to sign up for Sprint PCS Vision Services might have jsmith003@sprint.com as his user name. If you want a particular user name, you can visit www.sprint.com and get the name you want – as long as nobody else already has it.

Note:	If you already have a Sprint PCS Mail User Name, that will automatically become your Sprint PCS Vision User name. Similarly, if you haven't yet set up your email account, your Sprint PCS Vision User Name will become your Sprint PCS Mail User Name.
--------------	---

Your user name will be automatically programmed into your phone. You don't have to enter it.

Finding Your User Name

If you aren't sure what your Sprint PCS Vision User Name is, you can easily find it online or on your phone:

- **At www.sprint.com:** Sign on to your account using your Sprint PCS Phone Number and account password. Click **My Personal Information** and then click **PCS Vision User Name** to display your user name.
- **On Your Phone:** You can find your user name under the **Phone Info** option in your phone's menu. (See your phone's User Guide for more information.)

Changing Your User Name and Password

If you have a particular name you'd like to use as your user name, you may change your assigned user name – as long as it isn't already in use. Your user name and Sprint PCS Vision password can be changed only from your PC online, not from your phone.

To change your user name or password:

1. From your PC, sign on to www.sprint.com.
2. Under the “Manage Your Account” heading, select **MY PCS Wireless**, enter your wireless phone number and your account password in the appropriate fields, and click **Log In**. (My PCS, which is your account management page, will be displayed.)

Note:

Your **account password** is the password you use to access your account information. It is set up when you activate your Sprint PCS Account. The default password is the last four digits of your Social Security number. Your Sprint **PCS Vision password** is separate from your account password and may be used to protect your Sprint PCS Vision account from unauthorized access. See “Your Sprint PCS Vision Password” on page 3 for further information.

3. Click **My Personal Information**.
4. Click **PCS Vision User Name** or **PCS Vision Password**.
5. Follow the onscreen instructions to change your user name or password and click **Submit**. (It will take several minutes for your changes to take effect. You must leave your phone on during this time.)

Your Sprint PCS Vision Password

Certain Sprint PCS Vision services, such as Premium Services purchases of ringtones, games, screen savers, or applications, may be protected by an additional Sprint PCS Vision password. When used with multiuser accounts, the Sprint PCS Vision password also protects individual user information stored in your email, address books, or calendar applications.

Creating Your Sprint PCS Vision Password

The optional Sprint PCS Vision password will only be set up if you use a service that requires a password, such as purchasing a Premium Services or accessing your email, calendar, or address book from your PC (on a multiuser account). At that point, you will be prompted to set up a Sprint PCS Vision password.

To set up your Sprint PCS Vision password:

1. Enter your password in the first field. (The password must be at least six characters long.)
2. Re-enter your password to confirm.
3. Choose a security question to use in case you forget your Sprint PCS Vision password and enter the answer.
4. Confirm that your phone is on and has a signal and click **Submit**. (Your password will be programmed into your phone and your account.)

You may also set up your Sprint PCS Vision password before you're asked for it. Just follow the instructions found in see "Changing Your User Name and Password" on page 3 to create your password.

Retrieving/Resetting Your Sprint PCS Vision Password

If you are prompted to enter your Sprint PCS Vision password and cannot remember it, you may retrieve or reset your password online at www.sprint.com.

- If you're trying to access your email, address book, or calendar from your computer and cannot remember your Sprint PCS Vision password, click the **I forgot my Sprint PCS Vision Password** link and answer your security question. Then, you may enter a new password which will take effect immediately online.
- If you're trying to make a Premium Services purchase and cannot remember your Sprint PCS Vision password, you must change your password online from your computer. Follow the instructions found in see "Changing Your User Name and Password" on page 3. If you are prompted to enter your password, click the **I forgot my Sprint PCS Vision Password** link and answer your security question. Then, you may enter a new password which will take effect immediately online.

Note:

When you enter a new Sprint PCS Vision password online, it becomes effective online immediately. There will be a delay before the new password becomes effective on your phone.

Launching a Sprint PCS Vision Connection

Now that you have your Sprint PCS Vision Service, you'll want to begin taking advantage of the benefits of Sprint PCS Vision by launching a data connection. Since your phone is automatically signed in to Sprint PCS Vision services, launching a data session is easy.


To launch a Sprint PCS Vision connection:

- ▶ From your phone's main menu, select **Web** and press **OK**.

Shortcut: You can also launch a Sprint PCS Vision connection by pressing the navigation key to the right in standby mode or by pressing the right softkey (**Web**), depending on your phone model.

Your Sprint PCS Vision connection will launch and the Sprint PCS Vision home page will be displayed.

The Sprint PCS Vision Home Page



While connecting, the following will be displayed on the screen: **Connecting....**

If you had a previous Sprint PCS Vision connection, the last Web page you visited will be displayed the next time you launch a connection. When this occurs, you may not see the “Connecting...” message when you begin the session. Although the browser is open and the Web page is visible, you are not currently in an active data session – that is, no data is being sent or received. When you navigate to another page, the active session will launch and you will see the “Connecting as...” message.

Important Note: When you launch Sprint PCS Vision, you may see one of the following messages: “Preparing data services. Please wait.” or “Preparing Vision services. Please wait.” This automatic process, called provisioning, should take only a few moments. If you cancel the process, you will not be able to access Sprint PCS Vision features.

Net Guard

When you first connect to the Internet, the Net Guard will be displayed to confirm that you want to connect. This feature helps you avoid accidental connections. You can disable the Net Guard in the future by selecting **Always Auto-Connect** when the Net Guard is displayed.




You may disable the Net Guard feature through your phone's **Settings** menu. For details, see your phone's User Guide.

Note: When enabled, the Net Guard is displayed only once per session.

The Net Guard is not displayed if the phone is merely reconnecting due to a time-out.

Sprint PCS Vision Connection Status and Indicators

Your phone's display lets you know the current status of your Sprint PCS Vision connection through indicators which are displayed at the top of the screen. The following symbols are used:

-  Your Sprint PCS Vision connection is active (data is being transferred). Incoming voice calls go directly to voicemail; outgoing voice calls can be made, but the Sprint PCS Vision connection will terminate.
-  Your Sprint PCS Vision connection is dormant (no data is being sent or received). The phone can restart an active connection quickly; voice calls can be made and received.
-  Your phone is not currently able to access Sprint PCS Vision service features.

If no indicator is displayed, your phone does not have a current Sprint PCS Vision connection. To launch a connection, see the instructions on page 5.

Navigating the Web With Your Phone

Throughout this guide you will encounter instructions involving scrolling, selecting, and entering information as you navigate through the Web on your phone. Below is a brief primer on how to navigate the Web and use the Sprint PCS Vision menus with your phone.

Note: The instructions included below may not reflect your phone's specific operation. For details on your phone model, please refer to your phone's User Guide.

Your Phone's Navigation Controls

Here is a list of the controls you will use most frequently when navigating the Web. For details on the location of specific buttons on your phone, please refer to the User Guide that was packaged with your phone, or visit www.sprint.com to access your phone's User Guide.

- **Softkeys:** The softkey text displays options or commands that correspond with the left and right softkey buttons.
- **Left Softkey Button:** Selects the actions or menus offered by the left softkey, often OK on the Web.
- **OK Key:** Selects highlighted options and confirms actions.
- **Right Softkey Button:** Selects the actions or menus offered by the right softkey, often **Menu** on the Web.
- **END Key:** Ends a Web session and returns your phone to standby mode.
- **Navigation Key:** Press **Up**, **Down**, **Left**, or **Right** to scroll through items and highlight options. To select options, highlight them and press **OK** to select.
- **BACK Key:** Returns you to the previous Web page or menu screen. Press and hold to return to the Sprint PCS Vision home page.

Browsing the Web

In order to use your Sprint PCS Vision services, you will need to learn how to browse, select menu items, and initiate actions within the Web. Once you get the hang of it, the whole world of Sprint PCS Vision will be at your fingertips wherever you are on the Nationwide Sprint PCS Network.

Softkeys

When browsing the Web, the bottom line of your phone's display contains one or more softkeys. These keys are shortcut controls for navigating around the Web, and they correspond to the softkey buttons directly below the phone's display screen. Depending on which Web sites you visit, the labels on the softkeys may change to indicate their function.

To use softkeys, simply press the desired softkey button. If an additional pop-up menu is displayed when you press the softkey button, select the menu items using your keypad (if they're numbered) or by scrolling to highlight the option and pressing **OK**.

Using the Navigation Key

The navigation key allows you to scroll through text and menus and to highlight options, menu items, and text entry fields.

- **Scrolling:** Press the navigation key up and down to scroll line by line through Web pages. (To scroll one page at a time, press the volume buttons on the side of the phone.)

- **Highlighting:** Press the navigation key up and down to highlight menu items, links, and text entry fields within Web pages.

Note: For the purposes of this guide, “**Highlighting**” and “**Selecting**” are different actions. “**Highlighting**” means using the navigation key to bring the emphasis of a page to an item, such as a link, a menu item, or a text entry field. “**Selecting**” is initiating the action indicated by the highlighted item, such as “Reply” when viewing an email; it typically involves pressing the **OK** key or the corresponding softkey button.

Selecting

Once you’ve learned how to use softkeys and the navigation key, you can start navigating Web sites and Sprint PCS Vision application pages.

- Select on-screen items by using the navigation key to highlight the desired item, then press the desired softkey button (or press **OK**). You’ll find that the left softkey is used primarily for selecting items. This softkey is often labeled “Go.”
- If the items on a page are numbered, you can use your keypad (number keys) to select an item.

Tip: The tenth item in a numbered list may be selected by pressing the **0** key on your phone’s keypad, even though the number 0 may not be displayed on the screen.

Links, which are displayed as underlined text, allow you to jump to different Web pages, select special functions, or even place phone calls.

- Select links by highlighting the link and then selecting the appropriate softkey.

Note: If you select a “Call” link to initiate a phone call (for example, when viewing an email), you will be asked to confirm the action. If you choose to place the call, your Sprint PCS Vision session will end.

Going Back

- ▶ Press the **BACK** key on your phone to go back one page. (Note that the **BACK** key is also used for deleting text, like a **BACKSPACE** key, when you are entering text.)

Going Home

- ▶ Press and hold **BACK** to return to the Sprint PCS Vision home page from any other Web page.

Reminder: The instructions included in this guide are illustrative only. Your phone’s operation and keys may differ. Please refer to your phone’s User Guide for details of your phone’s specific operation.

Managing Sprint PCS Vision Online

While this guide deals primarily with how to use your exciting Sprint PCS Vision services from your phone, many of the applications can be accessed and managed from your home computer by signing on to **My PCS** at www.sprint.com. Since text entry is easier from your computer, the online management options can be particularly useful when setting up address books or editing preset message lists. Managing these options online will make using Sprint PCS Vision services from your phone even more convenient and efficient.

To access My PCS (your account management page):

1. From your computer, sign on to www.sprint.com.
2. Under the “Manage Your Account” heading, select **MY PCS Wireless**, enter your wireless phone number and your account password in the appropriate fields, and click **Log In**. (My PCS, which is your account management page, will be displayed.)

Note:

Your account password is the password you use to access your account information. It is set up when you activate your Sprint PCS Account. The default password is the last four digits of your Social Security number.

From **My PCS**, you can access and manage the following Sprint PCS Vision applications:

- **Sprint PCS Picture MailSM**: Click the **Picture Mail** link in the My Online Tools section. You will be redirected to the Sprint PCS Picture Mail Web site, where you can access the picture management applications.
- **Sprint PCS Mail**: Click the **PCS Mail** link in the My Online Tools section to go to the email page. From there you can access your inbox; compose, read, reply to, and forward email messages; manage your address book; change your settings and preferences; set up distribution lists; and more.
- **Text Messaging**: Click **Text Messaging** in the My Online Tools section to go to the Text Messaging page. From there you can compose, read, reply to, and forward Text Messages; add or amend your preset messages list; reorder the icons list; change your settings and preferences; and more.
- **Content Catalog – Games, Ringers, Screen Savers, and Applications**: Click the appropriate category under the PCS Vision Services heading, or click **Content Catalog** to view the entire content list. You can browse through, preview, and purchase downloadable Premium Services content online. Purchased items are stored in My Content Manager and can be downloaded to your phone. (For more information, see “Using My Content Manager” on page 52.)



Sprint PCS Picture MailSM

Share it when it happens.

- ◆ Share your moments instantly.
- ◆ Put a face to your callers and see who is calling.
- ◆ Personalize your screen saver.
- ◆ Store precious memories in a mobile photo album.

Just point, click, and share.

With Sprint PCS Picture Mail, you can instantly shoot, share and print sharp high resolution, digital pictures and take and send short video clips with your phone.

Use your phone to take full-color digital pictures or video clips with sound. Then either store the pictures and videos or send them from your phone to email addresses or other Sprint PCS Vision-enabled phones. It's that easy.

Archive your pictures and videos at www.sprint.com/picturemail and take advantage of the Web site's advanced features, which let you crop pictures, organize your own albums, share your pictures and videos, order prints, and more.

Note:

Your phone's Camera and Camcorder settings and menu options may differ from those outlined in this guide. Please refer to your phone's complete User Guide for details.



Taking Pictures

Taking pictures with your phone is as simple as choosing a subject, pointing the lens, and pressing a button. For details on how to use all the features of your camera phone, please see your phone's User Guide.

To take a picture:

1. From the phone's main menu, select **Pictures**.
2. Select **Camera** to activate Camera mode.
3. Using the phone's main LCD as a viewfinder, aim the camera lens at your subject.
4. Press the Camera button to take the picture. (You will see "Saving" and the picture will be displayed.)
5. Press the right softkey (**Next** or **Options**) to display picture options, or press the Camera button to return to Camera mode to take another picture.

Note:

The instructions in this guide may not match your phone's operation. Please refer to your phone's User Guide for complete phone operation instructions.

Creating Your Sprint PCS Picture Mail Password

The first time you attempt to upload, share, or use the Sprint PCS Picture Mail Web site, you will need to establish a Sprint PCS Picture Mail password through your phone. This password will also allow you to sign in to the Sprint PCS Picture Mail Web site at www.sprint.com/picturemail, where you can access and manage your uploaded pictures.

To create your Sprint PCS Picture Mail password:

1. When prompted, enter a four-digit password using numbers or letters and press **OK**.

Tip:

Write down your Sprint PCS Picture Mail password in a secure place.

2. Please wait while the system creates your account.

Once you have received confirmation that your account has been successfully registered, you may upload and share pictures and access the Sprint PCS Picture Mail Web site.



Recording Videos

Recording videos with your phone is as simple as choosing a subject, pointing the lens, and pressing a button. For details on how to use all the features of your video phone, please see your phone's User Guide.

To record a video:

1. From the phone's main menu, select **Pictures**.
2. Select **Camcorder** to activate Video mode.
3. Using the phone's main LCD as a viewfinder, aim the camera lens at your subject.
4. Press the Camera button (or **Record**) to begin recording the video.
5. Press the Camera button again (or press **Stop**) to stop recording. (Recording will stop automatically after 15 or 30 seconds, depending on your phone.)
6. Press **Play** to play the video, or press **Next** to display additional video options, or press the Camera button to return to Video mode and take another video.

Note:	The instructions in this guide may not match your phone's operation. Please refer to your phone's User Guide for complete phone operation instructions.
--------------	---



Sharing Sprint PCS Picture Mail

Once you've taken a picture or a video, you can instantly share it with family and friends. You can send pictures and videos to their email addresses or to their messaging-ready phones.

Sharing Sprint PCS Picture Mail From "In Phone"

Note: The instructions in this guide may not match your phone's operation. Please refer to your phone's User Guide for complete phone operation instructions.

1. From the In Phone menu, scroll to highlight the picture you'd like to send and select **Send**.

Tip: To enter the In Phone menu from the Pictures menu, select **My Albums > In Phone**. From Camera mode, select **Options > Review/Send Media > In Phone**.

2. Add up to 10 recipients for the Sprint PCS Picture Mail by entering a recipient's 10-digit wireless phone number, by entering an email address, by selecting a recipient from your phone's Contacts list, or by selecting **Recent List** to choose from a list of your most recent Sprint PCS Picture Mail recipients.
3. Select **Next** when you have finished selecting or entering recipients.
4. To record and include a voice memo with the picture you are sending, select **Start** and start recording after the beep. (Maximum recording time is 10 seconds.)

Tip: Select **Skip** to continue without recording a voice memo.

5. Use your keypad to enter a text message.
– or –
Select **Options**, then **Canned Msg** or **Recent Msg** to display a list of preset messages; scroll to highlight the desired message and press **Select** to attach the message.

Tip: Select **Next** to continue without adding a text message.

6. Select **Next**. (The Preview screen will be displayed.)





7. Confirm the recipients, message, voice memo, and picture.
 - To change a recipient: highlight the recipient field and select **Change**; highlight the recipient; select **Options**; and add a new recipient, edit the selected recipient's contact information, or erase the selected recipient. (Select **Next** to return to the **Preview** page.)
 - To change or confirm a voice memo: highlight the voice memo or audio field and select **Review** to display the voice memo options:
 - ◆ **Play** to play back the voice memo.
 - ◆ **Record** to record the voice memo again.
 - ◆ **Erase** to erase the voice memo.
 - To change or confirm a text message: highlight the text message field and select **Change**; add or edit the message; and press **OK** to return to the **Preview** page.
8. Select **Send** to send the picture.

Sharing Videos From “In Phone”

1. From the In Phone menu, scroll to highlight the video you'd like to send, press **Options**, and select **Send Video**.

Tip: To enter the In Phone menu from the Pictures menu, select **My Albums > In Phone**. From Camcorder mode, select **Options > Review/Send Media > In Phone**.

Tip: Select **Next** (or leave the Message field blank) to continue without adding a text message.

2. Once you have selected the video you wish to send, follow steps 2-8 in “Sharing Sprint PCS Picture Mail From ‘In Phone’” on page 13.



Sharing Sprint PCS Picture Mail From Messaging

You can also share your pictures and videos from your phone's Messaging menu.

1. From the phone's main menu, select **Messaging**.
2. Select **Send Message**, then select **Picture** to display the Send Picture menu. (For videos, select **Video** to display the Send Video menu.)
3. Select **From My Pics.**, **From miniSD**, **Take Picture**, or **Online Albums** to select a location for the picture. (For videos, select **From My Albums**, **From miniSD**, **Take Video**, or **Online Albums** to select a location for the video.)
4. Select the picture(s) or video(s) you wish to send, then press **Next**.
5. Select **Recipients**.
6. To complete and send the Sprint PCS Picture Mail, follow steps 2-8 in "Sharing Sprint PCS Picture Mail From 'In Phone'" on page 13.

Note:

Sharing Sprint PCS Picture Mail from Messaging is available only on select Sprint PCS Vision-enabled phones.

Storing Pictures and Videos

Depending on your phone's settings, pictures and videos you take are automatically stored in the **In Phone** area of **My Albums**. (See your phone's user guide for information on adjusting the auto-save options.)

Pictures: My Albums – In Phone

Once a picture has been taken and saved to the In Phone area, you can access it by selecting **My Albums > In Phone**. You may also access the In Phone menu from Camera mode by selecting **Options > Review/Send Media > In Phone**. In this menu, you can view all your pictures, send Sprint PCS Picture Mail, assign pictures to phone tasks, send pictures to the Sprint PCS Picture Mail Web site, delete images, and access additional picture options.

Select **Options** to display your phone's In Phone options, which may include the following:

- **Go to Camera** (or **Take New**) to switch to Camera mode.
- **Upload** to select **Upload This** or **Upload All**, allowing you to upload a single picture or all the pictures saved in the In Phone menu to the Sprint PCS Picture Mail Web site. Depending on your settings, you may be prompted to accept a Sprint PCS Vision connection.



Note: Uploading sends a copy of selected pictures to the Sprint PCS Picture Mail Web site; it does not erase the picture from your In Phone menu. Uploaded pictures will be available in your In Phone menu until you choose to erase them.

Pictures can also be uploaded from the Online Albums menu. Go to **Pictures > My Albums > Online Albums > Upload Pics**, then select the pictures you wish to upload, and press **Upload**.

- **Erase** to select **Erase This** or **Erase All** to erase a single picture or all the pictures saved in the In Phone menu.

Note: Erasing pictures will free up memory space in your phone, enabling you to take more pictures. Once erased, pictures cannot be uploaded to your online Sprint PCS Picture Mail account.

- **Edit Caption** to edit the picture's caption.
- **Picture Info** to display information on the selected picture, such as caption, size, time/date, and more.
- **Thumbnail/Expand** to switch the display from full-screen to thumbnail view (up to nine pictures per screen, depending on your phone's display).
- **Assign** to assign selected pictures to phone tasks, such as screen savers, incoming call alerts, Contacts entry identifiers, and more.

Note: Pictures may be assigned to more than one task.

Videos: My Albums – In Phone

Once a video has been recorded and saved to the In Phone area, you can access it by selecting **My Albums > In Phone**. You may also access the In Phone menu from Video mode by selecting **Options > Review/Send Media > In Phone**. The In Phone menu lets you play all the videos you have recorded, share videos, assign video clips to phone tasks, send video clips to the Sprint PCS Picture Mail Web site, delete videos, and access additional video options.

To play a video from the In Phone menu:

1. From the In Phone menu, use your navigation key to highlight the video you wish to play.
2. Press **Play**. (The video will play on your phone's main display screen.)

To access additional "In Phone" options:

- ▶ Select **Options** to display your phone's In Phone options (options will vary by phone model). To select an option, highlight it and press **OK**.



- **Send Video** to send a video clip via Sprint PCS Video Mail. (See steps 2-8 under “Sharing Videos From ‘In Phone’” on page 14.)
- **Thumbnail/Expand** to switch the display from full-screen to thumbnail view (up to nine pictures per screen, depending on your phone’s display).
- **Upload** to select **This Video File** or **All Video Files**, allowing you to upload a single video clip or all the videos saved in the In Phone menu to the Sprint PCS Picture Mail Web site. Depending on your settings, you may be prompted to accept a Sprint PCS Vision connection.

Note: Uploading sends a copy of selected videos to the Sprint PCS Picture Mail Web site; it does not erase the picture from your In Phone menu. Uploaded pictures will be available in your In Phone menu until you choose to erase them.

Videos can also be uploaded from the Online Albums menu. Go to **Pictures > My Albums > Online Albums > Upload Video**, select the videos you wish to upload, and press **Upload**.

- **Assign** to assign the selected video to a phone task, such as an animated screen saver or a ringer.
- **Erase** to select **This Video File** or **All Video Files** and erase a single video or all the videos saved in the In Phone menu.

Note: Erasing videos will free up memory space in your phone, enabling you to record more videos. Once erased, videos cannot be uploaded to your online Sprint PCS Picture Mail account.

- **Edit Caption** to edit the video’s caption.
- **Video Info** to display information on the selected video, such as caption, size, and time/date.
- **Go to Saved to Phone** to display the Saved to Phone video menu.
- **Go to Camcorder** to switch to Video mode.

Note: Videos may be assigned to more than one task.

Managing Sprint PCS Picture Mail



Using the Sprint PCS Picture Mail Web Site

Once you have uploaded pictures and videos from your phone to your online Sprint PCS Picture Mail account (see “Pictures: My Albums – In Phone” on page 15), you can use your personal computer to manage your pictures and videos. From the Sprint PCS Picture Mail Web site, you can share pictures and videos, edit album titles and picture captions, organize and move images, and do much more.

You will also have access to image management tools to improve and customize your pictures and videos. You’ll be able to lighten, darken, crop, antique, add comic bubbles and cartoon effects, and use other features to transform your pictures and videos.

To access the Sprint PCS Picture Mail Web site:

1. From your computer’s Web browser, go to www.sprint.com/picturemail.
2. Enter your Sprint PCS Phone Number and your Sprint PCS Picture Mail password to sign in. (See “Creating Your Sprint PCS Picture Mail Password” on page 11.)

Managing Online Pictures and Videos From Your Phone

You can use your phone to manage, edit, or share pictures and videos that you have uploaded to the Sprint PCS Picture Mail Web site. (See “Pictures: My Albums – In Phone” on page 15 for information about uploading.)

To view your online pictures and videos from your phone:

1. From the phone’s main menu, select **Pictures**.
2. Select **Online Albums**, then select **View Albums**. Depending on your settings you may be prompted to accept a Sprint PCS Vision connection. (Your Sprint PCS Picture Mail Inbox and your albums are displayed.)
3. Highlight **Inbox** or an album title and press **OK** to display the selected pictures. (Thumbnail images are displayed, up to nine per screen, depending on your phone model.)
4. Use your navigation key to select a picture or video.

Tip: To expand a selected picture from thumbnail to full-screen, select **Options > Expand**.



Sharing Online Sprint PCS Picture Mail

To share Sprint PCS Picture Mail from online mode:

1. From the online Sprint PCS Picture Mail display, select a picture or video you wish to share, and select **Options**. (See “Managing Online Pictures and Videos From Your Phone” on page 18.)
2. Highlight **Send Picture** or **Send Video** and press **OK**.
3. Select **Recipients**, then select **Contacts** or **Online Addr. Book** and press **OK**.
4. Highlight a recipient from your phone’s Contacts list or Online Address Book and press **OK**.
5. To complete and send the Sprint PCS Picture Mail, follow steps 2-8 in “Sharing Sprint PCS Picture Mail From ‘In Phone’” on page 13.

To share an album from online mode:

1. From the online Albums display, select an album you wish to share, and select **Options**. (See “Managing Online Pictures and Videos From Your Phone” on page 18.)
2. Highlight **Share Album** and press **OK**.
3. Follow steps 2-5 in “Sharing Online Sprint PCS Picture Mail” above to complete and send your Sprint PCS Picture Mail.

Accessing Online Picture and Video Options From Your Phone

1. Select a picture from your online Sprint PCS Picture Mail. (See “Managing Online Pictures and Videos From Your Phone” on page 18.)
2. Select **Options**. (To select an option, highlight it and press **OK**.)
 - **Expand** to expand the picture or video from thumbnail view to full-screen view.
 - **Send Video** (video only) to share a video through the Sprint PCS Picture Mail Web site. (See “Sharing Online Sprint PCS Picture Mail” on page 19.)
 - **Copy/Move** to copy or move pictures or videos to a selected album:
 - ◆ **Move Selection** to move the selected picture or video to the album.
 - ◆ **Move All** to move all the pictures or videos in the current album (or Inbox) to the target album.
 - ◆ **Copy Selection** to copy the selected picture or video to the album.
 - ◆ **Copy All** to copy all the pictures or videos in the current album (or Inbox) to the target album.
 - **Display/Edit** to display information and edit a picture or video.
 - ◆ **Text Caption** to display, add, or change the item’s caption.



- ◆ **Picture Info/Video Info** to display information about the picture or video.
- ◆ **Full Screen** (picture only) to expand the picture to full-screen mode.
- ◆ **Rotate** (picture only) to rotate the selected picture.
- ◆ **Original Size/Enlarged View** (video only) to view the video in its original size or in an expanded view.
- **Delete** to select **Selected Pictures (Selected Videos)** or **All Pictures (All Videos)**, allowing you to erase a single picture or video or all the pictures or videos saved in the current album (or Inbox).
- **Save to Phone** to save the picture or video to your phone.
 - ◆ **Set as** to assign the selected picture or video to a phone task.
 - ◆ **Download Only** to save the picture or video to your phone.
- **Picture Info** to display information on the selected picture, such as title, size, time/date, and more.
- **Create Album** to create a new album (from the Inbox only). Enter the album name and select **Save** (left softkey).
- **Online Albums** to return to the online albums list.



Messaging

Share the moment.

- ◆ Send a quick email to coworkers or friends while you're sitting in a meeting.
- ◆ Hold a private conversation – even in a noisy room.
- ◆ Join a wireless chat room and meet new people.

Stay connected.

Sprint PCS Vision gives you more ways than ever to keep in touch. Using your phone's Web access and the Sprint messaging service, you can send and receive email and exchange instant text messages, or even join a chat room and discuss your favorite topics with others.

- ◆ **Text Messaging** – Send, receive, and reply to short text messages instantly with your phone.
- ◆ **Instant Messaging** – Stay connected with AOL® Instant Messenger, Yahoo!® Instant Messenger, and MSN® Messenger right from your phone.
- ◆ **Email** – Send and receive email on your phone with Sprint PCS Mail, Yahoo!® Mail, MSN® Hotmail, AOL® Mail, and EarthLink®.
- ◆ **Wireless Chat** – Participate in live chat rooms from your phone.



Accessing Messaging at www.sprint.com

Many of the messaging functions available on your phone can be accessed and managed through **My PCS** at www.sprint.com.

To access your online messaging options:

1. From your personal computer, go online and navigate to www.sprint.com.
2. Under the “Manage Your Account” heading, select **MY PCS Wireless**, enter your wireless phone number and your account password in the appropriate fields, and click **Log In**. (My PCS, which is your account management page, will be displayed.)
3. In the **My Online Tools** section, click the Sprint **PCS Mail** link to go to the Sprint PCS Mail page, or click **Text Messaging** to go to the Text Messaging page. From there you can access your inbox; compose, read, reply to, and forward messages; manage your address book; change your settings and preferences; and more.

SMS Text Messaging

With Text Messaging, you can use other people’s wireless phone numbers to send brief text messages from your wireless phone to their messaging-ready phone – and they can send messages to you.

Signing Up for SMS Text Messaging

You do not need to sign up for SMS Text Messaging. It can be accessed from your SMS-enabled phone as long as you have service and are on the Nationwide Sprint PCS Network.

If you have added a Sprint PCS Vision Pack to your Sprint PCS Service Plan, a set number of SMS Text Messages may be sent and received per month at no additional charge. Individual SMS Text Messages that are not included in your plan or plan upgrade will be subject to a per-message charge. Please refer to your Sprint PCS Service Plan for further details.

Sending SMS Text Messages

To create and send SMS text messages:

1. From the main menu, select **Messaging**.
2. Select **Send Message**.
3. Select **Text**.





4. Enter a recipient for your new text message.
 - Select **Mobile Phone#**, enter the phone number of the recipient(s), press **OK**, and press **Next**.
– or –
 - Select **Email Address**, enter the email address of the recipient(s), press **OK**, and press **Next**.
– or –
 - Select **Contacts** and use your navigation key to select up to 10 recipients. When you have finished adding recipients, select **Done** and press **Next**.

Tip: You may also have an option (**From Recent**) to add recipients from recently sent messages.

5. Compose a message (up to 160 bytes – approximately 160 characters, including spaces [size varies by device]) or use the preset messages or icons.
 - To compose a message, highlight the **Message** box and use your keypad to type a message. (Use the right softkey to select a character input mode. For more information about entering text, see your phone’s User Guide.)
 - To use a preset message or “emoticon”: select **Options** (or **Mode**) and press **OK**; select **Preset Msgs** or **Emoticons** from the drop-down options; select **Go**; then select the preset message or emoticon you wish to insert and select **OK**. (For more information on using preset messages, see “Managing Preset SMS Text Messages” on page 24.)

6. Review your message and select **Send**.

A confirmation will be displayed, along with a disclaimer stating that the message can only be delivered if the recipient has a compatible Internet-ready wireless phone.

Displaying New SMS Text Messages

1. When you receive a text message, you will see the message text on your phone’s display screen. Select **View** to view the complete message.

Tip: You may also access the inbox directly at any time. From your phone’s main menu, select **Messaging > Text Msg > Inbox**.

2. When you have finished viewing the text message, press **End** to return to standby mode, press **Reply** to compose a reply, or press **Options** to display additional options.



Replying to SMS Text Messages

1. Display a message from your text messaging inbox. While the message is open, select **Reply**.
2. Compose a reply or use the preset messages or icons.
 - To type a reply, highlight the **Message** box and use your keypad to type a message. Use the right softkey to select a character input mode.
 - To use a preset message or “emoticon”: select **Options** (or **Mode**) and press **OK**; select **Preset Msgs** or **Icons** from the drop-down options; select **Go**; then select the preset message or emoticon you wish to insert and select **OK**.
3. Review your reply and select **Send**.

Managing Preset SMS Text Messages

To make sending messages from your phone faster and easier, SMS Text Messaging comes with a variety of preset messages. You have the ability to edit these messages and to add new ones of your own.

To add, edit, or remove preset messages:

1. From the main menu, select **Settings**.
2. Select **Messaging**.
3. Select **Preset Msgs** (or **Canned Msgs**).
4. From the preset messages menu, select a message you wish to edit and press **OK**.
5. Using your keypad, enter your new message or changes and select **Save**.

Note:

SMS Text Messaging comes with 26 preset messages, but it is capable of storing up to 61 messages (varies by phone model). You can add customized messages until you reach this limit. When the limit is reached, you must remove an existing message before you can add a new one.

Instant Messaging

Sprint PCS Vision also provides you with access to popular instant messaging (IM) clients, including AOL® Instant Messenger™, MSN® Messenger, and Yahoo!® Messenger.

Accessing Instant Messaging

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Instant Messaging**.
3. Select an instant messaging host, such as **AOL Instant Messenger**, **MSN Messenger**, or **Yahoo! Messenger**.
4. Use your keypad to enter the required sign-in information for the selected provider, such as user name or password, and select **Sign In**. (Your IM screen for the selected provider will be displayed.)

Note:

The information required to sign in will vary depending on the instant messaging provider you are accessing.

5. Follow the onscreen instructions to read, reply to, compose, send, and manage your IM account.



Email – Sprint PCS Mail

With Sprint PCS Mail, you can set up an account at no additional charge and perform many of the typical email functions from your phone that you can from your personal computer.

You can manage your Sprint PCS Mail account from your phone or from your personal computer at www.sprint.com. You can also access other select email providers from the Web.

Note: The instructions in this section outline how to access your phone's messaging capabilities from the Sprint PCS Vision home page. Please note that you may also access Sprint PCS Mail and additional email options through your phone's main menu by selecting **Messaging > IM & Email**. These options will launch your browser and take you to the corresponding messaging page.

Setting Up Your Sprint PCS Mail Account

You may set up your Sprint PCS Mail account directly from your phone or online at www.sprint.com.

To set up your Sprint PCS Mail account from your phone:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**, and then select **PCS Mail**. (The browser will go to the Sprint PCS Mail main menu.)
3. Using your keypad, enter your Sprint PCS Vision User Name and Password. (See "Your Sprint PCS Vision User Name" on page 2.)

Your inbox, including your Welcome email, will be displayed. Your Sprint PCS Mail account is now active and ready to use.

To set up your Sprint PCS Mail account online:

1. From your PC's Web browser, go to www.sprint.com and sign on to **My PCS** with your Sprint PCS Phone Number and account password.
2. Click **My Online Tools** then click the **PCS Mail** link. (The Sprint PCS Mail sign-up page will be displayed.)
3. Since you've already been assigned your Sprint PCS Vision User Name, that will become your Sprint PCS Mail User Name. (For more information about your Sprint PCS Vision User Name, including selecting a new user name, see "Your Sprint PCS Vision User Name" on page 2.)
4. Enter a password in the New Password field, re-enter it in the Confirm field, and click **Done**.

Your inbox, including your Welcome email, will be displayed. Your Sprint PCS Mail account is now active and ready to use.





Accessing Sprint PCS Mail Messages

To access Sprint PCS Mail messages from your phone:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**, and then select **PCS Mail**. (The browser will go to the Sprint PCS Mail main menu.)

Note:

You may also access the Sprint PCS Mail menu from your phone's main menu. Just select Messaging > Email. (Your browser will start and display the Sprint PCS Mail main menu.)

If you're a first-time user, your phone will prompt you to set up your Sprint PCS Mail account by establishing a user name and password. (See "Setting Up Your Sprint PCS Mail Account" on page 26.)

3. To view your incoming messages, select **Inbox** and press **OK**. (A list of your incoming Sprint PCS Mail messages will be displayed, detailing the sender information, subject, and date the email was received.)
4. Scroll to highlight the message you wish to read and press **OK**. (The selected message will be displayed.)

Note:

Depending on your settings, you may receive a text notification on your phone when you receive a new Sprint PCS Mail message. Select **Go** to launch the browser and go to the Sprint PCS Mail inbox.

5. Use the phone's navigation key to scroll through the message line-by-line or use the volume button to scroll one page at a time.

Reminder:

For information on navigating, highlighting, and selecting items on the Web from your phone, see "Navigating the Web With Your Phone" on page 6.

End of Message Options

When you reach the end of a Sprint PCS Mail message, you will encounter a list of options. To select an option, highlight it and press **OK**.

- **Reply** to send a response to the sender. Scroll down to highlight the Message box and use your keypad to type a reply. (Use the right softkey to select a character input mode.) When you have finished composing your reply, select **Send**.

Note:

When sending a Sprint PCS Mail reply, you may also add additional email addresses, amend the reply address, add CC recipients, and mark the reply as urgent. For details on using these options, see "Sending Sprint PCS Mail Messages" on page 28.



- **Reply All** to send a response to the sender and all other recipients of the message. Follow the instructions above to compose and send your reply.
- **Forward** to forward the message to another email address. Select **To**, choose a recipient from your address book, and press **OK**, or select the addressee box and enter an email address for the recipient. If you wish to compose additional text for the forwarded message, highlight the **Message** box and compose your message. (For further details on composing messages, see “Sending Sprint PCS Mail Messages” on page 28.)
- **Erase** to erase the message.
- **Add to Folder** to add the message to a folder. Highlight the desired folder and press **OK**. (For more information on using folders, see “Managing Sprint PCS Mail Folders” on page 29.)
- **Main** to return to the Sprint PCS Mail main menu.

Sending Sprint PCS Mail Messages

To compose and send Sprint PCS Mail messages from your phone:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**, and then select **PCS Mail**. (The browser will go to the Sprint PCS Mail main menu.)
3. Select **Compose**.
4. Enter a recipient for your new Sprint PCS Mail message:
 - Highlight **To** and press **OK** to display your Sprint PCS Mail address book. To add a recipient, highlight a listing and press **OK**; repeat to add additional recipients from your address book.
– or –
 - Select the addressee box (under or next to **To**) and enter the email address of the recipient.
5. Repeat the above step for CCs and BCCs if necessary.
6. Select the **Subject** text entry field and enter the subject.
7. Select the **Message** field and enter your message.
8. Select **Send** when your message is ready to be delivered.

Tip:

For more information about entering text and composing messages, please see your phone’s User Guide.



Managing Sprint PCS Mail Folders

As with other PC-based email accounts, your Sprint PCS Mail account allows you to organize your messages into folders for easy reference.

To create a new folder:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**, and then select **PCS Mail**. (The browser will go to the Sprint PCS Mail main menu.)
3. Select **Folders**.
4. Select **New Folder**.
5. Enter the name of the new folder and select **Save**.

To delete a folder:

1. From the Folders menu (see steps 1-3 above), select the folder you wish to delete.
2. Select **Delete Folder**. (A confirmation will be displayed. Select **Delete** to confirm.)

To rename a folder:

1. From the Folders menu (see steps 1-3 in see “To create a new folder:” on page 29), select the folder you wish to rename.
2. Select **Rename Folder**.
3. Enter the new folder name and select **Rename**.

Using Your Calendar

Your Sprint PCS Mail account includes a calendar function which allows you to keep track of your scheduled appointments even while you're on the go.

To access your Sprint PCS Mail Calendar:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**, and then select **PCS Mail**. (The browser will go to the Sprint PCS Mail main menu.)
3. Select **Calendar**. (The current date and any appointments for the day will be displayed. Select the arrows at the top of the page to display the next or previous day.)

To add an event to the calendar:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**, and then select **PCS Mail**. (The browser will go to the Sprint PCS Mail main menu.)



3. Select **Add Appt.** (You can also add an appointment from the Calendar view by selecting **New Appt.**) The current month’s calendar will be displayed.
4. Select the day to which you would like to add an appointment.
5. To fill in the appointment details, enter the appropriate information in the following fields. Select **Next** after each entry.
 - **Set Time/Duration:** Enter a Start Time and an End Time for the appointment or select **All Day Event**.
 - **Subject:** Enter a subject or a title for the appointment.

Once you’ve entered the first two fields, the **Enter Appointment** page will be displayed. You can enter information in the following fields as needed. After each entry you will return to the Enter Appointment page.

- **Location:** Enter a location.
- **Description:** Enter an event description.
- **Reminder:** Schedule a reminder for the appointment. Select **None.**, **15 Min.**, **30 Min.**, **1 Hr.**, **2 Hrs.**, **4 Hrs.**, **1 Day.**, or **1 Week**.
- **Invitations:** Send email invitations for the appointment. Select **[Enter Address]** to enter an email address. Select **[Lookup Address]** to add attendees from your address book. Select **Done** when you’re finished.
- **Recurrence:** Select **None**, **Daily**, **Weekly**, **Monthly**, or **Yearly**.

When you’ve added all the information you want to include, select **Save**. The appointment will be added to your calendar.

Managing Your Contacts

Your Sprint PCS Mail account includes a contact list that allows you to organize your frequent contacts in a convenient location.

Note: Your Sprint PCS Mail contacts list is separate from the Contacts feature accessible through your phone’s main menu.

To access your Contacts:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**, and then select **PCS Mail**. (The browser will go to the Sprint PCS Mail main menu.)
3. Select **Contacts**. (A list of your contacts will be displayed.)
4. Select a contact to display the entry’s information, or to edit or delete the contact’s listing.



To add an entry to the Contacts list:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**, and then select **PCS Mail**. (The browser will go to the Sprint PCS Mail main menu.)
3. Select **Add Contact**. (You can also add a contact from the Contacts view by selecting **Add New Contact**.) The New Contact page will be displayed.
4. Enter a **First Name**, **Last Name**, **Email Address**, and **Phone #** for the entry.

Note: To assign a label for the phone number (mobile, work, home), click the label (the default is Mobile Phone #) to open a drop-down list, and choose the desired label.

5. Select **Add Details** to include additional contact information or **Save** to save the entry as is.

If you select the **Add Details** option, you may enter or edit the following contact information:

- **Name** (last and first), **Email 1**, **Email 2**, **Mobile Phone #**, **Work Phone #**, **Home Phone #**, **Nickname**, **Company**, **Title**, **Address**, or **Comments**.

Using the Task List

Your Sprint PCS Mail account lets you track ongoing projects through a Task List.

To add a project to the Task List:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**, and then select **PCS Mail**. (The browser will go to the Sprint PCS Mail main menu.)
3. Select **Task List**. The Tasks menu will be displayed in the currently saved view. (To change the Tasks view, select **View** and choose a new view: **Today**, **Week**, **Active**, or **Overdue**.)
4. Select **New**.
5. To fill in the Task details, enter the appropriate information in the following fields. Select **Next** after each entry.
 - **Subject:** Enter a subject for the task entry.
 - **Select due date:** Using your navigation key, highlight a due date for the task. To proceed to the next month's view, select the arrow to the right of the currently displayed month's name.

Once you've entered the first two fields, the **Edit Task** menu will be displayed. You can enter information in the following fields as needed. Select **Next** after each entry and you will return to the **Edit Task** menu.



- **Description:** Enter a description for the task.
- **Reminder Date:** Schedule a reminder for the appointment. The Set Reminder page will open. Select **Send to Phone** or **Send to email** and select **Next**. The Reminder page will open. Select **None.**, **15 Min.**, **30 Min.**, **1 Hr.**, **2 Hrs.**, **4 Hrs.**, **1 Day.**, or **1 Week**.
- **Recurrence:** Select **None**, **Daily**, **Weekly**, **Monthly**, or **Yearly**.
- **Status:** Select a completion status for the task: **Not Started**, **25% Complete**, **50% Complete**, **75% Complete**, or **100% Complete**.

When you've entered all the information you want to include, select **Save**. The task will be added to your list.

To view and edit Task List projects:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**, and then select **PCS Mail**. (The browser will go to the Sprint PCS Mail main menu.)
3. Select **Task List**. The **Tasks** menu will be displayed in the currently saved view. (To change the Tasks view, select **View** and choose a new view: **Today**, **Week**, **Active**, or **Overdue**.)
4. Select the task you wish to view or edit.
5. The **Edit Task** menu will be displayed. Scroll through to view the task details or select a detail and edit it as outlined in step 5 on the preceding page.

Accessing External Email Accounts

Your Sprint PCS Vision account allows you to access selected external email providers over the Web from your phone. You must first configure your Sprint PCS Mail to receive email from external accounts.

To configure your Sprint PCS Mail to receive email from external accounts:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**, and then select **PCS Mail**. (The browser will go to the Sprint PCS Mail main menu.)
3. Select **Settings**.
4. Select **Other Email**. (The **Other Email** sources menu is displayed.)
5. Select **Add Source**.
6. Select a provider from the list of compatible external email providers, such as AOL® Mail, Yahoo!® Mail, EarthLink®, and MSN® Mail, or select **Other** to enter information from an additional provider.
7. Enter your User ID and Password as indicated and select **Save**.



Your Sprint PCS Mail is now configured to retrieve mail from your external email account. Your Sprint PCS Mail account can store settings for up to five external email accounts.

Online Option:	You can configure your Sprint PCS Mail settings online at www.sprint.com . Sign on to your account with you Sprint PCS Phone Number and account password and click the PCS Mail link in the My Online Tools section. Click the “ Settings & Preferences ” link to display your Sprint PCS Mail Settings & Preferences. Select the Setup tab and choose the settings you would like to edit, including External Email Source. Follow the onscreen instructions to make your changes.
-----------------------	--

To access External Email accounts from your phone:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**, and then select **PCS Mail**. (The browser will go to the Sprint PCS Mail main menu.)
3. Once you have configured your Sprint PCS Mail account to retrieve external email, incoming external email messages will be delivered to your email inbox. Select **Inbox** to view all incoming messages.

To edit or delete External Email accounts from your Sprint PCS Mail setup:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**, and then select **PCS Mail**. (The browser will go to the Sprint PCS Mail main menu.)
3. Select **Settings**.
4. Select **Other Email**. (The **Other email Sources** menu is displayed.)
5. Select an external email provider from the list of configured sources.
6. To edit the account, select and make changes to the Server Name, User ID, or Password fields as needed, and select **Save**. To delete the account, select **Erase**. (A confirmation dialog will be displayed; select **Yes** to confirm the deletion.)

Reminder:	For information on scrolling and on highlighting and selecting items on the Web from your phone, see “Navigating the Web With Your Phone” on page 6.
------------------	--



Managing Your Sprint PCS Mail Settings

You can manage many of your email options through the Sprint PCS Mail Settings menu.

To access the Settings menu:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**, and then select **PCS Mail**. (The browser will go to the Sprint PCS Mail main menu.)
3. Select **Settings**.
4. Select an option from the Settings menu to access these additional features:
 - **From Name:** Enter the name you want to display in the “From” field for all of your outgoing messages.
 - **Vacation Message:** Enable or disable auto-reply email for when you’ll be away. Enter a **Start Date**, **End Date**, **Subject**, and **Message**, and select **Save**.
 - **Notification:** Configure Sprint PCS Mail or phone notification for select incoming emails. (See “Notification Settings” on page 35.)
 - **Forwarding:** Forward your Sprint PCS Mail to another email account. Enter the email address to which you would like your incoming Sprint PCS Mail forwarded and select **Save**. Your Sprint PCS Mail account will maintain a copy of all forwarded messages.
 - **Change Time Zone:** Set the time zone used by your Sprint PCS Mail account. Choose a time zone and select **Save**.
 - **Change Password:** Change the password used to access your Sprint PCS Vision account. Enter and re-enter your new password and select **Save**. For more information on passwords, see “Your Sprint PCS Vision Password” on page 3.
 - **V-Card:** Enable or disable automatic V-Card attachments for outgoing email messages. Choose **ON** or **OFF** and select **Save**.

Note:

V-Cards are the standard for electronic business cards. To create your V-Card, you must sign on to your account at www.sprint.com and access the Sprint PCS Mail Settings & Preferences area. Click the **Signatures** folder, enter your V-Card information, and select your V-Card settings.

- **Other Email:** Configure your Sprint PCS Mail account to retrieve email from select providers via the Web. (See “Accessing External Email Accounts” on page 32.)
- **Main:** Return to the Sprint PCS Mail main menu.



Notification Settings

You can configure your Sprint PCS Mail account to send notifications to other email addresses or to your phone whenever you receive selected incoming Sprint PCS Mail messages.

To set up your Notification preferences:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**, and then select **PCS Mail**. (The browser will go to the Sprint PCS Mail main menu.)
3. Select **Settings**.
4. Select **Notification**.
 - To set up email notification, select **Email Notification**, enter an email address (you may send notification to up to three separate email addresses), choose the type of email for which you want to send notification (**All email**, **None**, or **Custom**) and select **Submit**. (If you select **Custom**, you may then choose to receive notification of Urgent emails or of emails from a specific email address or addresses which you supply.)
 - To set up notification to your phone, select **PCS Phone**, choose the type of email for which you want to send notification (**All email**, **None**, or **Custom**), and select **Submit**. (If you select **Custom**, you may then choose to receive notification of Urgent emails or of emails from a specific email address or addresses which you supply.)
5. Select **Save** to update your Notification options and press **OK** to return to the Settings menu.

Email – Additional Email Providers

With Sprint PCS Vision, you can use popular email services such as AOL® Mail, Yahoo!® Mail, MSN® Hotmail, and EarthLink® to keep in touch even while you're on the go.

Accessing Email

To access email providers from your phone:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Email**.
3. Select an email provider, such as **AOL Mail**, **Yahoo! Mail**, **MSN Hotmail**, or **EarthLink**.
4. Use your keypad to enter the required sign-in information for the selected provider, such as user name, email address, or password, and select **Sign In**. (Your mailbox for the selected provider will be displayed.)

Note:

The information required for sign-in will vary depending on the email provider you are accessing.

5. Follow the onscreen instructions to read, reply to, compose, send, and manage your email account.

Reminder:

You can set up your Sprint PCS Mail account to receive and manage email from external email providers. See “Accessing External Email Accounts” on page 32.



Wireless Chat

Sprint PCS Vision gives you the ability to join graphically-enhanced wireless chat rooms and discuss your favorite topics in real time from your phone. Wireless Chat provides instant text communication with others from the U.S. or from around the world. To join a chat room, simply sign on and start typing.

Experiencing a Chat Room

To access Wireless Chat from the browser:

1. From the Sprint PCS Vision home page, select **Messaging**.
2. Select **Chat & Dating**.
3. Select **Jumbuck**.
4. Highlight a category (**Fast Flirting** or **Power Chat**) and press **Go**.
5. Select **Enter**. You will see a disclaimer for Wireless Chat. Select **I Agree** to enter the Chat menu.
6. Use your keypad to enter a nickname and select **Enter**.
7. Highlight a chat room from the menu (for example, Singles, Over 20s, or Flirts) and press **Go**. Once in the chat room, you may scroll through the postings to read messages from other chat room participants. To update the displayed messages, select **Manual refresh**.

Note:

To avoid inadvertent data usage charges, you should log out of chat rooms when you are ready to exit.

To post a message:

1. Select **Add Text**.
2. Enter your message. Use your right softkey to select a text entry mode.
3. Select **Send**.





To set up a private chat room:

1. Select **1->1**.
2. Select a participant with whom you'd like to launch a private chat room. A message will be sent to the person's chat screen (or to yours if someone is requesting a private chat with you): [Nickname] requested a 1->1. Do u accept? **Yes No**
If the invited party accepts, a private chat room will launch.

To exit a chat room:

- ▶ Select **Leave Room**.

Accessing Wireless Chat Help

To read a brief overview of how to use Wireless Chat and a list of common softkey abbreviations, just select **Help** from the Wireless Chat main menu.



Hi-quality video & sound on the go.

- ◆ Access hundreds of clips a day using Sprint TVSM – with more added all the time.
- ◆ Subscribe to premium channels to get the content you want, when you want it.
- ◆ Catch up on all the latest sports, news, entertainment, and more.

Let your Sprint TV-capable phone entertain, inform – even amaze you.

Sprint brings the excitement of streaming video and audio to select Sprint PCS Vision-enabled phones. See and hear the latest news, sports, weather, and more in full-color video and vivid sound while on the go – anytime, anywhere, on the Nationwide Sprint PCS Network. It's like having a TV in the palm of your hand.



Exploring Sprint TV Services

Sprint TV services offer a wide variety of channels depending on the features and options you select.

- **Preview Channel** – Sample programming from all the available premium channels for free before you subscribe. Take a test drive, and then select the channels that suit you best.
- **Sprint TVSM** – This comprehensive basic service presents a variety of continually updated content from familiar brands. Think of it as “basic cable” for your phone.
- **Available Individual Channel Options** – Subscribe to available individual “premium” channels from an expanding menu from top brands you know, covering the world of news, entertainment, sports, weather, and much, much more.

You can always visit www.sprint.com for a comprehensive up-to-date channel guide with programming and subscription rate information.

Accessing Your Channel Listings

Sprint TV and other media content is accessible through your phone’s built-in media player. It’s easy to find and view your channel listings from your phone’s main menu.

To access your channel listings:

- ▶ From the phone’s main menu, select **Media Player > Channel Listings**, and then select a category (**Sprint TV, Music & Radio, Entertainment, News & Weather, Sports, Cartoons, Mobile Shorts, or Stylez**). Your channel listings will be displayed, divided into the following categories:
 - **My Channels:** These include any individual channels for which you have purchased access. If you have purchased Sprint TV, either through a Sprint TV Vision Plan subscription or by purchasing it separately, it will be displayed here.
 - **Previews:** These are complimentary samples of available programming. To view a preview, just highlight the clip you wish to see and press **Select**.
 - **Available Channels:** These are channels that have not yet been purchased but are available for a monthly subscription fee.

Note: The instructions in this guide may not match your phone’s operation. Please refer to your phone’s User Guide for complete phone operation instructions.

Purchasing New Media Channels

There are two ways to purchase and access available multimedia channels: online at www.sprint.com or directly from your phone's media player menu.

Purchasing Media Channels on Your Phone

1. From the phone's main menu, select **Media Player > Channel Listings > [category]** to display your channel listings.
2. Select a channel from the **Available Channels** menu, either by entering the channel number or by highlighting the desired channel and pressing **Select**.
3. Follow the onscreen prompts to purchase access to the selected channel.

Purchasing Media Channels Online

As with many other features of Sprint PCS Vision, you can purchase and manage your available multimedia channels through the **My PCS** tool at www.sprint.com.

To purchase multimedia channels online:

1. From your personal computer, go online and navigate to www.sprint.com.
2. Under the "Manage Your Account" heading, select **MY PCS Wireless**, enter your wireless phone number and your account password in the appropriate fields, and click **Log In**. (My PCS, which is your account management page, will be displayed.)
3. Select the **Content Catalog** link at the bottom of the Welcome page.
4. Select **Browse Media Player Content** to find the channel(s) you wish to purchase.
5. Select the desired channel and follow the onscreen instructions to purchase access to the selected channel.

The next time you access your channel listings from your phone, the selected channel will be displayed in the **My Channels** section of the channel listings for the corresponding category.

Playing Media Clips

Watching clips with your phone's media player is as simple as choosing channels on your TV set. Just choose a channel, select a clip, and enjoy.

To play a multimedia clip:

1. From the phone's main menu, select **Media Player > Channel Listings** to display your channel listings.
2. Select a channel from one of the **My Channels** menus, either by entering the channel number or by highlighting the desired channel and pressing **Select**. (A list of available clips will be displayed.)

Note:

You may also select a channel from the Available Channels menu. You will be prompted to accept a monthly fee before continuing.

3. Choose the clip you'd like to see and press **Select**. (The clip will automatically load and begin playing.)



Music

Whatever kind of music you want, Sprint PCS Vision can deliver it right to your phone.

- ◆ Listen to the best in commercial-free, digital music from SIRIUS Music.
- ◆ Stream your favorite music right to your phone from a variety of available music channels.

Sprint lets you turn your music-capable phone into your own personal concert hall with a variety of music channels available to listen to on your phone's built-in media player. Listen to all kinds of music including R&B, Hip-Hop, Country, and Rock while keeping up with headlines and video clips of artist interviews and performances.



Accessing Your Music Channel Listings

Music & Radio content is accessible through your phone's built-in media player. It's easy to find and view your channel listings from your phone's main menu.

To access your channel listings:

- ▶ From the phone's main menu, select **Media Player > Channel Listings > Music & Radio**. Your channel listings will be displayed, divided into the following categories:
 - **My Channels:** These include any individual music channels for which you have purchased access.
 - **Available Channels:** These are channels that have not yet been purchased but are available for a monthly subscription fee.

Note:	The instructions in this guide may not match your phone's operation. Please refer to your phone's User Guide for complete phone operation instructions.
--------------	---

Purchasing New Music Channels

There are two ways to purchase and access available music channels: online at www.sprint.com or directly from your phone's media player menu.

Purchasing Media Channels on Your Phone

1. From the phone's main menu, select **Media Player > Channel Listings > Music & Radio** to display your channel listings.
2. Select a channel from the **Available Channels** menu, either by entering the channel number or by highlighting the desired channel and pressing **Select**.
3. Follow the onscreen prompts to preview or to purchase access to the selected channel.





Purchasing Media Channels Online

As with many other features of Sprint PCS Vision, you can purchase and manage your available multimedia channels through the **My PCS** tool at www.sprint.com.

To purchase multimedia channels online:

1. From your personal computer, go online and navigate to www.sprint.com.
2. Under the “Manage Your Account” heading, select **MY PCS Wireless**, enter your wireless phone number and your account password in the appropriate fields, and click **Log In**. (My PCS, which is your account management page, will be displayed.)
3. Select the **Content Catalog** link at the bottom of the Welcome page.
4. Select **Browse Media Player Content**, and then select **Music & Radio** to find the channel(s) you wish to purchase.
5. Select the desired channel, and follow the onscreen instructions to purchase access to the selected channel.

The next time you access your music channel listings from your phone, the selected channel will be displayed in the **My Channels** section of the channel listings for the corresponding category.

SIRIUS Music

SIRIUS Music channels offer a variety of great commercial-free music that you can access directly from your phone.

To access SIRIUS Music on your phone:

1. Select **Menu > Media Player > Channel Listing > Music & Radio > SIRIUS MUSIC.**
2. Select **Preview** to see and hear a preview of the SIRIUS Music service.
– or –
Select **Buy** to purchase a monthly subscription to SIRIUS Music.

Once you have purchased access to the SIRIUS Music service, you can select from the following stations to listen to your favorite music:

- **SIRIUS Hits 1:** Today's Top 40 Hits.
- **The Pulse:** Pop and Rock from the '90s to now.
- **'60s Vibrations:** The musical revolution of the '60s and early '70s.
- **Totally '70s:** The most popular music from the '70s.
- **Big '80s:** The hit music of the '80s.
- **Classic Vinyl:** Classic rock of the '60s and '70s.
- **Alt Nation:** The best alt-rock of the '90s and today.
- **Hot Jamz:** Today's hip-hop and R&B hits.
- **Heart & Soul:** The R&B hits from the '80s, '90s and today.
- **Prime Country:** Country music superstars of yesterday and today.
- **Jazz Café:** Smooth jazz instrumentals and vocals.
- **SIRIUS Blues:** Authentic blues music, from past to present.
- **Broadway's Best:** Songs from Broadway's most popular shows.
- **The Beat:** Today's biggest dance hits and remixes.
- **Area63:** Trance and progressive house dance music.
- **SIRIUS INTERVIEWS:** Interviews and performances of favorite artists.

Streaming Music

Sprint PCS Vision offers a multitude of additional choices in music and radio channels for your phone.



Sprint PCS Vision Premium Services Downloads

Get in on the fun.

With your new phone, you have access to a variety of downloadable Premium Services content, including Games, Ringers, Screen Savers, and Applications. Have fun customizing your phone with Music Tone ringers and entertaining images, and enjoy playing the latest games.

It's easy to use.

This section explains how to access, purchase, and download Premium Services content on your phone. (Additional charges may apply when downloading Premium Services content; see your Sprint PCS Service Plan for details.)

- ◆ Finding content to download
- ◆ Purchasing content
- ◆ Downloading content to your phone
- ◆ Using www.sprint.com for downloads



Accessing the Download Menus

To access the Sprint PCS Vision download menus:

- ▶ From the Sprint PCS Vision home page, select **Downloads**, then select **Games**, **Ringers**, **Screen Savers**, or **Applications**. The corresponding Content Catalog or menu will be displayed. (For more information on navigating the Web, see “Navigating the Web With Your Phone” on page 6.)

You can also access the download menus from your phone’s main menu:

1. Select **My Content**.
2. Select the type of file you wish to download (**Games**, **Ringers**, **Screen Savers**, or **Applications**) and press **OK**.
3. Select **Get New** and press **OK**. The browser will launch and take you to the corresponding download menu.

Finding an Item to Download

From the download menus, you may search for items to download in a number of ways:

- **Featured** displays a rotating selection of featured and seasonal items.
- **Categories** allows you to narrow your search to a general category, such as “Pop” or “Country” for Ringers or “Art Gallery” for Screen Savers. Select a category to display a list of the available corresponding items.
- **Search** allows you to use your keypad to enter search criteria to find an item. You may enter an entire word or title or perform a partial-word search. (For example, entering “goo” returns “Dr. Feel Good,” “Good Hearted Woman,” and “Goofy – Gawrsh.”)

Note:

The availability of specific content is dependent on a particular handset’s software version and hardware (display, audio) specifications. Not all content is available on all handsets.

Downloading an Item

Once you've decided on an item to download, highlight it and press **OK**. You will see an item detail page which includes the item's title, the vendor, the price, the expiration term, and the estimated file size. Select onscreen links to view additional information:

- **Description** shows the title, a brief description of the purpose of the download, the vendor name and phone number, the version number, and the date of its most recent update.
- **License Info** displays the title, price, license type, license duration (the length of time you have use of the download), and the legal description of the license.
- **Terms of Use** displays the Premium Services Terms of Use.

Note:

When you download content for use on your phone, you are purchasing the rights to access that content for a period of time as specified in the item description. The cost for purchasing these rights varies from item to item and will be clearly stated before you make your purchase.

To download a selected item:

1. From the summary page, select **Buy**. (The item will automatically download to your phone. You will see a series of screens detailing the download initiation, progress [in bytes], and the saving process. When the **New Download** screen is displayed, the item has been successfully downloaded to your phone.)

(If you have not previously purchased an item, you will be prompted to create your purchasing profile to authorize Premium Services purchases. See "Authorizing Premium Services Purchases" on page 50.)

2. Choose your next action or option once the download is complete.
 - Select **Listen** (or **View**) to listen to a ringer or view a screen saver.
 - Select **Run** to launch a game or an application.
 - Select **Set As** to assign a ringer or screen saver to a phone task.
 - Select **Settings** to view network and registry information about a game or an application
 - Select **Shop** to browse for other items to purchase and download.
 - Press **END** to quit the browser and return to standby mode.

Authorizing Premium Services Purchases

The first time you attempt to purchase a Premium Services item from your phone, you will be asked to create your purchasing profile to authorize Premium Services purchases on your account.

To create your purchasing profile:

1. When you attempt to make a Premium Services purchase and the Purchase Authorization prompt is displayed, enter your Sprint PCS Account Password. (The **Authorize User** screen displays, along with your user name and a link to the Premium Services Terms of Use.)

Note:

Your account password is the password you use to access your account information. It is set up when you activate your Sprint PCS Account. The default password is the last four digits of your Social Security number.

2. Select **Next**. (The **Authorization Complete** screen will be displayed.)
3. Select **Next** to complete your purchase and continue with your download.

Once you have completed your purchase authorization, you will not need to enter your account password to make future purchases. If you want a password to be required each time a Premium Services purchase is made on your account, you may sign on to **My PCS** at www.sprint.com, set up a Sprint PCS Vision password (if you haven't already done so), and set your preferences such that your Sprint PCS Vision password will be required for all purchases. For further details, see "Your Sprint PCS Vision Password" on page 3.

Managing Purchases at www.sprint.com

In addition to accessing Premium Services content from your phone, you may also browse content and make purchases from **My PCS** at www.sprint.com. Taking advantage of the online Content Catalog makes finding and buying content quick and easy.

To make Premium Services purchases online:

1. From your computer, sign on to www.sprint.com.
2. Under the “Manage” tab, select **MY PCS Wireless**, enter your wireless phone number and your account password in the appropriate fields, and click **Log In**. (My PCS, which is your account management page, will be displayed.)
3. Under “PCS Vision Services,” click the **Content Catalog** link or click the individual links for Games, Ringers, Screen Savers, or Applications to browse lists of all available Premium Services content and applications. (You may narrow your search within a category by selecting a subcategory from the drop-down list, or you may use the Search Content field to enter your own search criteria.)
4. Click an item’s name or the details icon to view information about the item, including:
 - Version number
 - Vendor name, phone number, and Web site link
 - File size and update date
 - Price
 - Links to the license text and Premium Services Terms of Use
5. To purchase the item, click **Buy it now**. (Additional charges, if applicable, will be displayed before completing the transaction.)

Your purchase will become available immediately in My Content Manager, and the My Content Manager folder will be displayed, along with a heading stating that a text message has been sent to your phone.

To use your newly acquired content, you must use your phone to download the files from My Content Manager. (You can also initiate the download directly from the link in the text message that is sent to your phone.) See “Using My Content Manager” on page 52 for details.

Using My Content Manager

Whether you purchase your Premium Services content from your phone or online from **My PCS**, all of your purchases are stored in **My Content Manager** and may be downloaded to your phone.

My Content Manager is a storage area on the Nationwide Sprint PCS Network that is assigned specifically to your account. It allows you to store all of your Premium Services downloadable files. The files remain in **My Content Manager** until their license terms have expired – even after you have downloaded the content to your phone. This provides you with a convenient place to access information about your downloaded files without having to store the information in your phone's memory.

To download purchased content from **My Content Manager**:

1. From the Sprint PCS Vision home page, select **Downloads**, then select **My Content Manager**.

Note: You can also access **My Content Manager** from your phone's main menu. Select **My Content** > [**Games, Ringers, Screen Savers, or Applications**] > **My Content Manager**. A Vision session will launch and take you to **My Content Manager**.

2. Select the item you wish to download. (The item summary page will be displayed.)
3. Select **Download** to initiate the download of the item. (You will see a series of screens detailing the download initiation, progress [in bytes], and saving process. When the **New Download** screen is displayed, the item has been successfully downloaded to your phone.)
4. Choose your next action or option after the download is complete.
 - Select **Listen** (or **View**) to listen to a ringer or to view a screen saver.
 - Select **Run** to launch a game or an application.
 - Select **Set As** to assign a ringer or screen saver to a phone task.
 - Select **Settings** to view network and registry information about a game or an application.
 - Select **Shop** to browse for other items to purchase and download.
 - Press **END** to quit the browser and return to standby mode.

Note: Content purchased online may be accessed directly from the text message sent to your phone upon purchase. Just select the link from the text message and press **OK** or **Go** to begin the download.



Games

Turn downtime into fun time.

- ◆ Improve your racing skills while waiting for the bus.
- ◆ Enjoy the excitement of gaming, by yourself or with other players.
- ◆ Make a long flight seem shorter with a challenging puzzle game.
- ◆ Play blackjack while standing in line at the grocery store.

Sprint has partnered with the most cutting-edge electronic gaming providers to bring you a realistic and exciting gaming experience. Advanced phones with full-color screens, vibration features, multi-chord sound, and sophisticated graphics make games from SEGA®, JAMDAT®, NAMCO®, THQ®, and Mobliss® more vivid than ever.



Types of Games – a small sampling

- ◆ **Action & Adventure**

Top Gun™ Air Combat by Mforma and Tom Clancy's *Splinter Cell*

- ◆ **Card & Board Games**

YAHTZEE® and Checkers by JAMDAT

- ◆ **Classic Games**

Bingo and Wizard Pinball

- ◆ **TV and Movies**

Wheel of Fortune™, *Family Feud®*, and *The Price Is Right*

- ◆ **Puzzles**

Tetris®, Tetris Cascade™, Betty Boop Crush, and Snood®

- ◆ **Retro and Arcade**

MS. PAC-MAN® by Namco, Frogger, Pac-Man®, Asteroids, and Q*Bert

- ◆ **Sports and Racing**

JAMDAT Bowling, 9-Ball Deluxe, JAMDAT Football, and Bowling Deluxe by Mforma

For a complete, updated listing of available games, use your computer to sign on to **My PCS** (see page 9) and click **See all Games**. For information on purchasing games online, see “Managing Purchases at www.sprint.com” on page 51.



Purchasing and Downloading Games



Tip: For complete instructions on downloading, see “Sprint PCS Vision Premium Services Downloads” on page 47.

To purchase and download games for your phone:

1. From the Sprint PCS Vision home page, select **Downloads**, and then select **Games**.
2. Use your navigation key to highlight and select a game you wish to download. (For more information on navigating the Web, see “Navigating the Web With Your Phone” on page 6.)

There are a number of ways you can browse for games:

- **Featured** displays a selection of highlighted games.
 - **Categories** allows you to narrow your search to a general category. Select a category to display a list of the available games within the category. Categories may change as different games become available.
 - **Search** allows you to search for a specific game. Use your keypad to enter a word or a partial word to search the Content Catalog for a game.
3. Once you have selected a game, the game detail page is displayed. (For information on what’s included on the detail page, see “Downloading an Item” on page 49.)
 4. From the game detail page, select **Buy**. (The game will download automatically. When the **New Download** screen is displayed, the game has been successfully downloaded to your phone.)

(If you have not previously purchased an item, you will be prompted to enter your account password and create your purchasing profile. See “Authorizing Premium Services Purchases” on page 50.)

5. Press **Next**, then select an option to continue:
 - Select **Run** to exit the browser and launch the game.
 - Select **Settings** to view network and registry information.
 - Select **Shop** to browse for other games to purchase and download.
 - Press **END** to quit the browser and return to standby mode.



To download games stored in My Content Manager:

1. From the Sprint PCS Vision home page, select **Downloads**, and then select **My Content Manager**.
2. Select the stored game you wish to download. (An information page will notify you that access to the game has been purchased and will be available through the stated expiration date.)
3. Select **Download** to download the game. (When the **New Download** screen is displayed, the game has been successfully downloaded to your phone.)
4. Press **Next**, then select an option to continue:
 - Select **Run** to exit the browser and launch the game.
 - Select **Settings** to view network and registry information.
 - Select **Shop** to browse for other games to purchase and download.
 - Press **END** to quit the browser and return to standby mode.

Playing Games

To play a downloaded game on your phone:

1. From your phone's main menu, select **My Content** (or **Downloads**).
2. Highlight **Games** and press **OK**.
3. Select the game you wish to play. (If applicable, a prompt will display the days remaining on the game license and ask if you want to continue. Select **Yes**.)
4. Follow the onscreen instructions to play the game. (Instructions and game options can usually be accessed through your phone's softkey buttons.)
5. When you have finished playing the game, select **Exit** (or **Quit**) or press **END**. (A prompt will be displayed: "Really terminate this application?")
6. Select **Yes** to exit or **No** to cancel.



Ringers

Music to your ears.

- ◆ Answer your phone to your favorite song.
- ◆ Assign different ringers to your friends so you always know who's calling.
- ◆ Screen your calls by their ring tones.

With your Sprint PCS Vision Service, you can personalize your wireless experience by downloading unique ringers and assigning them to numbers in your Contacts list. Select from thousands of available ringers – including your favorite tunes and celebrity voice ringers – and download them to your phone.





Types of Ringers – The Choices Are Endless

- ◆ **Music Tones** – Hear actual clips of the hottest popular hits of yesterday and today – performed by the original artists. From Alternative, Rock, and Hip-Hop to Country, Pop, Latin, and Motown, you’ll find what you’re looking for.
- ◆ **Bling Tones** – Answer your phone to awesome beats laid down by top hip-hop producers such as Lil’ Jon, Chucky Thompson, Mr. Porter, DJ Twinz, Rockwilder, Allstar, and more.
- ◆ **Famous Voices** – Hear voices – from celebrities and sports stars to Disney characters and plain ol’ folks – asking you to come to the phone. Jessica Simpson, Donald Duck, Snoop Dogg, and Tiger Woods are among the hundreds of voice ringers available.
- ◆ **College Fight Songs** – Get fired up to answer the phone with real music ringers featuring your favorite college fight songs as performed by their marching bands. From “Rocky Top” Tennessee to “Fight On” USC, dozens of the nation’s best are represented.
- ◆ **TV, Movie & Show Tunes** – Choose from your favorite television show themes, movie music, Broadway show tunes, video game themes – even Monty Python.
- ◆ **And more** – You can also choose from hundreds of traditional polyphonic ring tones in over a dozen categories, seasonal favorites, and anthems from more than three dozen nations.

For a complete, updated listing of available ringers, use your computer to sign on to **My PCS** (see page 9) and click **See all Ringers**. For information on purchasing ringers online, see “Managing Purchases at www.sprint.com” on page 51.

Purchasing and Downloading Ringers

Tip:

For complete instructions on downloading, see “Sprint PCS Vision Premium Services Downloads” on page 77.

To purchase and download ringers for your phone:

1. From the Sprint PCS Vision home page, select **Downloads**, and then select **Ringers**.
2. Use your navigation key to highlight and select a ringer you wish to download. (For more information on navigating the Web, see “Navigating the Web With Your Phone” on page 6.) There are a number of ways you can browse for ringers:
 - **Featured** displays a selection of highlighted ringers.
 - **Categories** allows you to narrow your search to a general category. Select a category to display a list of the available ringers or subcategories within the category. Categories may change as different ringers become available.
 - **Search** allows you to search for a specific ringer. Use your keypad to enter a word or a partial word to search the Content Catalog for a ringer.
3. Once you have selected a ringer, the ringer detail page is displayed. (For information on what’s included on the detail page, see “Downloading an Item” on page 49.)
4. From the ringer detail page, select **Buy**. (The ringer will automatically be downloaded to your phone.)
5. (If you have not previously purchased an item, you will be prompted to enter your account password and create your purchasing profile. See “Authorizing Premium Services Purchases” on page 50.)
6. Press **Next**, then select an option to continue:
 - Select **Listen** to play the ringer.
 - Select **Set as** to quit your Sprint PCS Vision session and assign the ringer to a phone task.
 - Select **Shop** to browse for other ringers to purchase and download.
 - Press **END** to quit the browser and return to standby mode.



To download ringers stored in My Content Manager:

1. From the Sprint PCS Vision home page, select **Downloads**, and then select **My Content Manager**.
2. Select the stored ringer you wish to download. (An information page will notify you that access to the ringer has been purchased and will be available until the stated expiration date.)

Note:

Once a ringer has been downloaded to your phone, it will remain available until you remove it from your phone. The expiration date refers to the length of time the ringer will be available for download from My Content Manager.

3. Select **Download** to download the ringer. (When the **New Download** screen is displayed, the ringer has been successfully downloaded to your phone.)
4. Press **Next**, then select an option to continue:
 - Select **Listen** to play the ringer.
 - Select **Set as** to quit your Sprint PCS Vision session and assign the ringer to a phone task.
 - Select **Shop** to browse for other ringers to purchase and download.
 - Press **END** to quit the browser and return to standby mode.

Assigning Downloaded Ringers

To assign downloaded ringers to specific events, such as incoming Caller ID calls or voicemail notifications, or to associate downloaded ringers to specific callers in your phone's Contacts list, refer to your phone's User Guide.



Screen Savers

Personalize your phone.

- ◆ Celebrate the holidays with different screen savers.
- ◆ Make it easier to tell who's calling by assigning different screen savers to people in your phone's Contacts list.
- ◆ Update your screen saver to match your mood.
- ◆ Answer your phone to images of your favorite cartoon character.

With your Sprint PCS Vision Service, you can personalize your wireless experience by downloading and assigning unique images for screen savers or to entries in your phone's Contacts list.





Show your true colors.

Personalize your phone by downloading vivid images from a wide variety of categories. You can also assign screen images to specific phone numbers in your address book.

- ◆ **Urban Stylez** – Give your phone some serious cred with graffiti, message “stickers,” Blender artwork, and more.
- ◆ **For The Ladies** – Have fun with Devil Girl, YM, Lucky Starrs, and other female-centric images.
- ◆ **For The Fellas** – Display your manly side with images from The History Channel, Socially Hazardous “stickers,” classic automotive art from Car & Driver, and more.
- ◆ **Models, Rock Stars & Celebs** – Swoon over your favorite celebrity pix.
- ◆ **Art Gallery** – Select from dozens of works by such masters as Cezanne, da Vinci, and Van Gogh.
- ◆ **On the Tube, Big Screen** – Display stills from hundreds of your favorite TV shows and movies.
- ◆ **And more** – You can also choose from other categories including Natural Wonders, World Traveler, Sports Fan, Cartoons & Comics, All About Me, and More Cool Stuff, as well as check out What’s New and What’s Hot.

To see the constantly updated library of available screen savers, use your computer to sign on to **My PCS** and click **See all Screen Savers**. For information on purchasing screen savers online, see “Managing Purchases at www.sprint.com” on page 51.

Purchasing and Downloading Screen Savers



To purchase and download screen savers for your phone:

Tip:

For complete instructions on downloading, see “Sprint PCS Vision Premium Services Downloads” on page 47.

1. From the Sprint PCS Vision home page, select **Downloads**, then select **Screen Savers**.
2. Use your navigation key to highlight and select a screen saver you wish to download. (For more information on navigating the Web, see “Navigating the Web With Your Phone” on page 6.) There are a number of ways you can browse for screen savers:
 - **Featured** displays a rotating selection of highlighted screen savers.
 - **Categories** allows you to narrow your search to a general category. Select a category to display a list of the available screen savers within the category. Categories may change as different screen savers become available.
 - **Search** allows you to search for a specific screen saver. Use your keypad to enter a word or a partial word to search the Content Catalog for a screen saver.
3. Once you have selected a screen saver, the screen saver detail page is displayed. (For information on what’s included on the detail page, see “Downloading an Item” on page 49.)
4. From the screen saver detail page, select **Buy**. (The screen saver will automatically be downloaded to your phone.)
5. (If you have not previously purchased an item, you will be prompted to enter your account password and create your purchasing profile. See “Authorizing Premium Services Purchases” on page 50.)
6. Press **Next**, then select an option to continue:
 - Select **View** to see your screen saver.
 - Select **Set as** to quit your Sprint PCS Vision session and assign the screen saver to a phone task.
 - Select **Shop** to browse for other screen savers to purchase and download.
 - Press **END** to quit the browser and return to standby mode.



To download screen savers stored in My Content Manager:

1. From the Sprint PCS Vision home page, select **Downloads**, then select **My Content Manager**.
2. Select the stored screen saver you wish to download. (An information page will notify you that access to the screen saver has been purchased and will be available to download from My Content Manager until the stated expiration date.)
3. To download the screen saver, select **Download**. (When the **New Download** screen is displayed, the screen saver has been successfully downloaded to your phone.)
4. Press **Next**, then select an option to continue:
 - Select **View** to see your screen saver.
 - Select **Set as** to quit your Sprint PCS Vision session and assign the screen saver to a phone task.
 - Select **Shop** to browse for other screen savers to purchase and download.
 - Press **END** to quit the browser and return to standby mode.

Assigning Downloaded Screen Savers

To assign downloaded screen savers to be displayed for specific events, such as powering on or off, or to assign downloaded screen savers to identify specific callers in your phone's Contacts list, refer to your phone's User Guide.



Web

Unlimited Web access keeps you informed on the go.

- ◆ Check out sports scores.
- ◆ Get your weather forecast on the move.
- ◆ Stay informed of the latest entertainment news.
- ◆ Check your flight status.
- ◆ Never miss the news.

Experience full-color graphic versions of popular Web sites wherever you go on the Nationwide Sprint PCS Network.



Web

With Web access on your phone, you will be able to browse full-color graphic versions – not just text versions – of your favorite Web sites, making it easier than ever to stay informed while on the go. Check sports scores, get the latest weather forecast, and stay on top of breaking news on your phone anywhere within the enhanced Nationwide Sprint PCS Network.

- **News:** CNNtoGo delivers up-to-the-minute coverage of news from the U.S. and around the world – 24 hours a day, 7 days a week.
- **Weather:** Get personalized weather and a seven-day forecast for over 80,000 locations worldwide from The Weather Channel.
- **Sports:** With ESPN®, you can get the most current scores, news, stats, and headlines as they happen. Whether you're trying to keep track of your fantasy team or you want the inside scoop on the big game, ESPN delivers the information you want from the source you can trust.
- **Entertainment:** E! Online, the number one entertainment Web site, delivers the latest celebrity and entertainment news, interactive polls, movie reviews, CD reviews, and more.
- **Travel:** Sabre® brings you up-to-the-minute itinerary and destination information via Virtually There®. You can also check your flight status from Sabre.
- **Money:** Fidelity AnywhereSM provides mobile investors with convenient access to their financial portfolios, market information, and trading. (Account access and trading capability are available on selected phones.)
- **Shopping:** Whether you're buying CDs, books, toys, electronics, or a wealth of other products and services, Amazon.com provides 1-click™ shopping from your phone.
- **Tools:** Search more than 3 billion Web pages and millions of images for the information you want.



Web

Using the Browser Menu

Navigating the Web from the Sprint PCS Vision home page is easy once you get the hang of it. For details on how to navigate the Web, select menu items, and more, see “Navigating the Web With Your Phone” on page 6.

Although the Sprint PCS Vision home page offers a broad and convenient array of sites and services for you to browse, not all sites are represented, and certain functions, such as going directly to Web sites, are not available. For these and other options, you will need to use the browser menu. The browser menu is a tools menu which offers additional functionality to expand your use of the Web.

Opening the Browser Menu

The browser menu may be opened from any page you are viewing during an active Sprint PCS Vision connection.

To open the browser menu:

- ▶ Press the right softkey button. (The browser menu will be displayed.)

Note:

The method for opening the browser menu may vary among phone models. Refer to your phone’s User Guide to determine how to open your phone’s browser menu.

The browser menu’s options include the following:

- **Home:** Returns the browser to the Sprint PCS Vision home page.
- **Forward:** Moves forward to a previously viewed page.
- **Mark this page:** Allows you to bookmark new sites. See “Bookmarks” on page 68.
- **View Bookmarks:** Allows you to view and access bookmarked sites. See “Bookmarks” on page 68.
- **Search:** Launches a Web search.
- **Show URL:** Displays the URL (Web site address) of the site you’re currently viewing.
- **Go to URL...:** Allows you to navigate directly to a Web site by entering its URL (Web site address). See “Going to a Specific Web site” on page 68.
- **History:** Keeps a list of links to your most recently visited Web sites. To navigate to a site, highlight it, press **OK**, and then select **Connect**.
- **Refresh this page:** Reloads the current Web page.
- **Restart Browser:** Refreshes the current browser session.
- **Send Page:** Allows you to send a copy of the current Web page using your phone’s messaging capabilities.



- **Preferences:** Allows you to configure and manage your browser settings. See “Browser Menu Settings” on page 69.

Bookmarks

Creating a Bookmark

Bookmarks allow you to store the address of favorite Web sites for easy access at a later time.

To create a bookmark:

1. Go to the Web page you want to mark.
2. Press the right softkey button.
3. Select **Mark this page**.
4. Use your keypad to edit the bookmark title and URL (if necessary) and select **Save** to save the bookmark.

Accessing a Bookmark

To access a bookmark:

1. Open the browser menu.
2. Select **View Bookmarks**.
3. Highlight the bookmark you'd like to access and press **OK** to go to the Web site.

Note:	Bookmarking a page stores only the page's address, not its contents. Some pages cannot be bookmarked. Whether a particular Web page may be marked is controlled by its creator.
--------------	---

Going to a Specific Web site

To go to a particular Web site by entering a URL (Web site address):

1. Open the browser menu.
2. Select **Go to URL....**
3. Select **Address**, and then select **Edit**.
4. Use your keypad to enter the URL of the Web site you wish to view, and then press **OK**.
5. Select **Connect** to go to the Web site.

Note:	The steps required to enter and navigate to a URL (steps 3-5 above) may vary from phone to phone.
	Not all Web sites are viewable on your phone.





Restarting the Web Browser

If the Web browser seems to be malfunctioning or stops responding, you can usually fix the problem by simply restarting the browser.

1. Open the browser menu.
2. Select **Restart Browser** and press **OK**. (The browser will restart and return to the Sprint PCS Vision home page.)

Browser Menu Settings

The **Preferences** option on the browser menu opens up the browser preferences menu. The items in this menu allow you to configure and manage your browser settings to suit your specific needs.

To select a preferences menu option, highlight it and press **OK**:

- **Edit Home Page:** Select **Edit**, then use your keypad to edit or enter a URL, and press **OK** twice to change your home page from the Sprint PCS Vision home page to one of your choosing.
- **Revert Home Page:** If you change your home page and want to reset it to the Sprint PCS Vision home page, select **Yes** and press **OK**.
- **Font Size:** Scroll to highlight a browser display font size and press **OK**.
- **Color Setting:** Scroll to highlight a browser color pattern setting and press **OK**.
- **Show Images:** Select **On** or **Off** and press **OK** to turn Web images on or off. (Turning images **Off** allows Web pages to load more quickly.)
- **Delete Cookies:** To delete stored cookies, select **Yes** and press **OK**.
- **Send Referrer:** Select **On** or **Off** and press **OK** to choose whether to have the browser send referrer information when accessing Web sites.
- **Title Tag:** Select **On** or **Off** and press **OK** to choose whether to accept title tags when accessing Web sites.
- **Sound Volume:** Use your navigation key to select a desired volume level.
- **About Browser:** Display browser version and copyright information.

Applications

With your Sprint PCS Vision Service, you can personalize your wireless experience by purchasing and downloading Web applications to suit your personal needs.

A sampling of available categories and applications (subject to change):

- **News:** Stay informed on the go with breaking stories, photos, business news, sports, op-ed pieces, and more from **NYTimes.com Mobile News powered by Vindigo™**.
- **Weather:** Be prepared, rain or shine, with personalized weather information from **WeatherBug Mobile Weather**.
- **Sports:** Get real-time sports scores and updates from the experts with **ESPN BottomLine**.
- **Entertainment:** Check out the latest movies, reviews, and local showtimes with **MovieGoer by Vindigo™**.
- **Travel:** Access address-to-address directions, create maps, and save your favorite routes with **Rand McNally Mobile Travel Tools**.
- **Comics:** Read your favorite daily comics on the go – including Doonesbury, Ziggy, Cathy, and others – with the **GoComics All-Star Six-Pack**.
- **Find It:** **MapQuest® Mobile Powered by Vindigo™** gives you national coverage, step-by-step directions, and color maps to help you get where you're going.
- **Shopping:** Monitor your **eBay®** bidding, shop, make bids, and compare prices right from your phone.

Tip:

For complete instructions on downloading applications, see “Sprint PCS Vision Premium Services Downloads” on page 47.

To see the constantly updated library of available applications, use your computer to sign on to **My PCS** and click **See all Applications**. For information on purchasing applications online, see “Managing Purchases at www.sprint.com” on page 51.





Media Applications

With media applications, Sprint brings the excitement of video and audio clips right to your phone. See and hear the latest news, sports, and weather information with slide-show pictures and sound – anytime, anywhere, on the Nationwide Sprint PCS Network.

Some of the available media content may include:

- **MobiTV™**: With a variety of 24/7 live news, sports, and entertainment channels from the cable and broadcast brands you know, MobiTV turns your phone into a portable TV.
- **1KTV**: Delivers sports, news, and information you can see and hear in an on-demand, multimedia, slide-show format.
- **Tabloid News**: The National Enquirer and the Weekly World News present their unique perspective on the news in an exclusive, multimedia, TV-like format.

Purchasing and Downloading Applications

To purchase and download applications for your phone:

1. From the Sprint PCS Vision home page, select **Downloads**, and then select **Applications**.
2. Use your navigation key to highlight and select an application you wish to download. (For more information on navigating the Web, see “Navigating the Web With Your Phone” on page 6.)
3. Once you have selected an application, the application detail page is displayed. (For more information, see “Downloading an Item” on page 49.)
4. From the application detail page, select **Buy**. (The application will automatically be downloaded to your phone.)
(If you have not previously purchased an item, you will be prompted to enter your account password and create your purchasing profile. See “Authorizing Premium Services Purchases” on page 50.)
5. Press **Next**, and then select an option to continue:
 - Select **Run** to launch the application.
 - Select **Settings** to view network and registry information.
 - Select **Shop** to browse for other applications to purchase and download.
 - Press **END** to quit the browser and return to standby mode.



To download applications stored in My Content Manager:

1. From the Sprint PCS Vision home page, select **Downloads**, then select **My Content Manager**.
2. Select the stored application you wish to download. (An information page will notify you that access to the application has been purchased.)
3. To download the application, select **Download**. (When the **New Download** screen is displayed, the application has been successfully downloaded to your phone.)
4. Press **Next**, and then select an option to continue:
 - Select **Run** to launch the application.
 - Select **Settings** to view network and registry information.
 - Select **Shop** to browse for other applications to purchase and download.
 - Press **END** to quit the browser and return to standby mode.

Launching Downloaded Applications

To launch and use downloaded applications:

1. From the phone's main menu, select **My Content** (or **Downloads**), and then select **Applications**.
2. Highlight the application you wish to launch and press **OK**. (The browser will launch and the application main page will be displayed.)
3. Follow the onscreen instructions to use the active application.



Sprint PCS Business ConnectionSM Personal Edition

Productivity in motion.

- ◆ Access your office email from the back of a taxi.
- ◆ Update your schedule in between meetings.
- ◆ Perform business tasks in real time.
- ◆ Stay productive even when you're miles away from the office.

Simple to connect. Simple to use.

Get secure, real-time access to Microsoft® Outlook® or Lotus Notes® information – including business email, calendars, company directories, and personal contacts – on any Sprint PCS Vision-enabled phone or mobile computing device while your PC is connected to your business network.

To learn more, visit businessconnection.sprint.com.



Sprint PCS Business ConnectionSM Personal Edition

Sprint PCS Business Connection Personal Edition gives you secure, real-time mobile access to your Microsoft® Outlook® or Lotus Notes® email, calendar, company directory, and personal contacts.

Sprint PCS Business Connection Personal Edition delivers the following features:

- **Business email access:** Read, reply to, forward, delete, compose, and select recipients for your company email.
- **Company directory and contacts:** Search, view, call, and email contacts from your company's directory. Do all this and add or edit your personal contacts.
- **Work calendar:** Accept and decline meetings, view daily summaries and details, and navigate to various dates.
- **Files/information on your PC:** Browse folders, download files, and view documents from any device using a PC browser or Pocket Internet Explorer.

Sprint PCS Business Connection Personal Edition requires no hardware or software installation on your company's network. Just install the Sprint PCS Business Connection Personal Edition software on your work computer. This allows data to be securely retrieved in real time by your wireless device when connected to the Nationwide Sprint PCS Network.

When your work PC isn't on, you can share connections with your coworkers so that you always have access to your email, calendar, and contacts. Your data remains secure behind the corporate firewall, and any changes you make on your wireless device are instantly updated on your company server without the need to synchronize.



Accessing Sprint PCS Business Connection

To access Sprint PCS Business Connection from your phone:

1. Launch the Web on your phone.
2. From the Sprint PCS Vision home page, select **Messaging**.

Note: From the Sprint PCS Vision home page, you may also select **More > Business Links**.

3. Under Biz Connection, select **Personal**.
4. Using your keypad, enter your Sprint PCS Business Connection User Name.
5. Enter your Sprint PCS Business Connection Password.
6. Select **Sign in**.

Once you've signed in to your account, you can take advantage of all the productivity-enhancing features of Sprint PCS Business Connection Personal Edition.

To access Sprint PCS Business Connection from your Palm®-powered phone:

1. Following the instructions in your Palm-powered phone's User Guide, download the Sprint PCS Business Connection for Palm client software to your device.
2. To access Sprint PCS Business Connection, tap the **Biz Conn** icon from the main menu.



Sprint PCS Vision FAQs

What is Sprint PCS Vision?

Sprint PCS Vision brings you clarity you can see and hear, with advanced multimedia services like email, pictures, and games that are easy to learn and use. All this – plus the voice clarity you’ve come to expect.

What are the benefits of Sprint PCS Vision?

Sprint PCS Vision allows you to stay in touch with your friends, have fun when you have a little down time, stay informed when you’re on the go, and personalize your device.

What services does Sprint PCS Vision provide?

Sprint PCS Vision offers you access to the following services and applications:

- **Sprint PCS Picture MailSM**: Take digital pictures and videos with your phone and send them to email addresses or other Sprint PCS Vision-enabled phones anytime, anywhere, on the Nationwide Sprint PCS Network. Imagine shooting pictures and videos and sending them to friends and family across the country – instantly.
- **Messaging**: Send and receive email and text messages or chat on your phone. With chat, you can have a conversation without talking. Join in a Web-based chat room to exchange information on a specific topic, or read conversations that others have posted – even launch a one-on-one chat for a more in-depth conversation.
- **Sprint TVSM**: See and hear the latest news, sports, weather, and more in full-color video and vivid sound while on the go. With a variety of channels available, it’s like having a TV in the palm of your hand.
- **Music**: Stream music to your phone’s built-in media player. With several channels available, choose from your favorite styles like Rock, Pop, Hip-Hop, and R&B. Plus, get exclusive video clips, performances, and interviews from your favorite artists.
- **Games**: Play exciting games with full-color graphics, sound, and vibration on your phone. Play popular games from categories such as retro, action, card, adventure, casino, sports, puzzles, classics, and more.
- **Ringers**: Personalize your phone by downloading unique ringers and assigning them to numbers in your address book, so you’ll know who’s calling by the sound of the ring.
- **Screen Savers**: Download unique images to use as screen savers – or make it easy to tell who’s calling by assigning specific images to numbers in your address book.



- **Web:** With Sprint PCS Vision, you will be able to browse full-color graphic versions of popular Web sites, making it easier than ever to stay informed while on the go. Check sports scores, breaking news, and weather, and shop from your phone.
- **Sprint PCS Business ConnectionSM:** Secure, real-time access to your Microsoft® Outlook® or Lotus Notes® company email, calendar, business directory, and personal contacts. You'll have the features and functions of your Microsoft Outlook and Lotus Notes so you can view, create, reply to, and delete email; schedule appointments; and look up phone numbers anywhere on the Sprint Nationwide PCS Network.

How do I take advantage of Sprint PCS Vision?

To experience the benefits of Sprint PCS Vision, you must purchase a Vision-enabled phone and a Sprint PCS Service Plan with Vision, or pay a per-kilobyte fee for casual usage. Even if you don't have a Sprint PCS Service Plan with Vision, Vision-enabled phones will allow you to take advantage of these services at a casual usage rate billed separately on your monthly invoice. Please see our Sprint PCS Service Plans section to determine which plan will best suit your needs.

How am I charged for Sprint PCS Vision Services?

Unlike voice calls, which are charged by the minute, data usage is charged by the size of file sent or received on your phone. If you have a Sprint PCS Service Plan with unlimited Sprint PCS Vision, your usage of Sprint PCS Vision is unlimited and you will not be charged any data fees. If you do not have unlimited Sprint PCS Vision, you will be charged for Sprint PCS Vision service on a per-kilobyte (KB) basis any time you transmit or receive information using your phone.

What is the Content Catalog?

The Content Catalog is where you can find a wide variety of downloadable content for your phone, including games, ringers, screen savers, and more. You need a Vision-enabled phone and a Sprint PCS Service Plan with Vision to access the Content Catalog.

How much does it cost to purchase items from the Content Catalog?

Items you find in the Content Catalog vary in price and may include no-cost items. Prices are listed for each item along with a description. You will be able to see how much an item costs before you decide whether to buy it.

Where is my content stored?

Items you purchase from the Content Catalog for your phone are stored in My Content Manager. You can access My Content Manager to download the content onto your handset for use.

How can I access My Content Manager?

You can access My Content Manager from your phone or by signing on at www.sprint.com:

- ▶ **From your phone:** Launch your browser by selecting **Web**. Phone models vary slightly, but you should now be on your Sprint PCS Vision home page. (If not, select it from the menu.) Select **Downloads**, and then select **My Content Manager**.
- ▶ **From your computer:** Sign on to your account at www.sprint.com (see page 9). Then, select one of the links under the **My Content Manager** tab.

What messaging options are available with Sprint PCS Vision?

Sprint PCS Vision Services offers a variety of messaging options that allow you to choose how to connect with your friends, family members, and coworkers. You can send and receive SMS Text messages, send and receive Sprint PCS Mail, use external email providers, use popular instant messaging clients, or chat 24 hours a day – in real time – on Sprint PCS Vision-enabled phones while on our Nationwide Sprint PCS Network.

Products, applications and services are subject to availability and change. Sprint PCS Vision is not available while roaming off the Nationwide Sprint PCS Network. Not all Sprint PCS Vision services and applications are available with all Sprint PCS Vision Devices. Sprint PCS Vision Services and Applications are optional and available for an additional charge. Plans/options with unlimited Sprint PCS Vision access are not available with phones used as a modem. Sprint PCS Vision services are also not available where use is in connection with server devices or host computer applications, other systems that drive continuous heavy traffic or data sessions, or as substitutes for private lines or frame relay connections. Sprint may deny or terminate service without notice for misuse. See service plan guide, mapping brochures and other in-store materials for full details.

© 2005 Sprint Nextel. All rights reserved. Sprint, the “Going Forward” logo, and other trademarks are trademarks of Sprint Nextel. MS, PAC-MAN® ©1980, 1982, 2005 Namco Ltd., All Rights Reserved. All other trademarks, logos and copyrights are property of their respective owners.

Index

A

- Account Password 3
- AOL® Instant Messenger 25
- AOL® Mail 36
- Applications 70
 - Launching 72
 - Purchasing and Downloading 71

B

- Back Key 7
- Bookmarks 68
- Browser Menu 67
 - Bookmarks 68
 - Opening 67
 - Settings 69
- Browsing the Web 7–8

C

- Calendar 29
 - Adding an Event 29
- Chat 37–38
- Connection Status 6
- Contacts 30
 - Accessing 30
 - Adding 31
- Content Catalog 9, 51
- Contents iii

D

- Downloading an Item 49
- Downloads 47
 - Accessing Menus 48
 - Authorizing Purchases 50
 - Finding Items to Download 48
 - Managing Online 51

E

- Earthlink® 36
- Email 36
- Entertainment 66

F

- FAQs 76

G

- Games 53
 - Playing 56
 - Purchasing and Downloading 55

H

- Home Page 5

I

- Instant 25
- Instant Messaging 25
- Introduction ii

L

- Links 8
- Lotus Notes® 74

M

- Messaging 21
 - Accessing Online 22
 - Chat 37–38
- Microsoft® Outlook® 74
- MSN Hotmail 36
- MSN® Messenger, 25
- Music 43–46

N

- Navigating the Web 6–8
 - Going Home 8
 - Highlighting 8
 - Links 8
 - Scrolling 7
 - Selecting 8
- Navigation Key 7
- Net Guard 6
- News 66

P

- Password
 - See Sprint PCS Vision Password or Account Password

R

- Ringers 57
 - Assigning 60
 - Purchasing and Downloading 59

S

- Screen Savers 61
 - Assigning 64
 - Purchasing and Downloading 63
- Scrolling 7
- Shopping 66
- SIRIUS Music 46
- SMS Text Messaging 22–24
 - Preset Text Messages 24
 - Sending SMS Text Messages 22
- Softkeys 7
- Sprint PCS Business Connection 73
- Sprint PCS Mail 26–35
 - Accessing Messages 27
 - Calendar 29
 - Managing Contacts 30
 - Managing Folders 29
 - Messages 27
 - Notification Settings 35
 - Sending 28
 - Setting Up 26
 - Settings 34
 - Task List 31
- Sprint PCS Picture Mail 10
 - Taking Pictures 11
- Sprint PCS Vision 1
 - Connection Status 6
 - FAQs 76
 - Home Page 5
 - Launching a Connection 5
 - User Name 2
- Sprint PCS Vision Password 3
 - Changing 3
 - Creating 3
 - Retrieving/Resetting 4

- Sprint PCS Vision User Name 2
 - Changing 3
 - Finding 2
- Sprint TV 39–42

T

- Taking Pictures 11
- Tools 66

U

- User Name 2
 - Changing 3
 - Finding 2

V

- V-Card 34

W

- Web 6, 65
 - Browsing 7
 - Navigating 6–8

Y

- Yahoo!® Mail 36
- Yahoo!® Messenger 25